

Magnavox

SERVICE MANUAL

THE MAGNAVOX COMPANY · SERVICE DEPARTMENT
FORT WAYNE, INDIANA

Manual No. 6500

File: 1974 "D" Series (Volume 11)
Miscellaneous Section
Second Issue: May, 1975

1TL200 BLAK & BK12 ODYSSEY GAME SIMULATOR





Figure 1 -- Odyssey Block Diagram

GENERAL DESCRIPTION

Odyssey is an electronic game simulator developed by Magnavox as a consumer leisure time product. The basic Odyssey set consists of a Master Control Unit, Game Cards, two Player Control Units, Antenna-Game Switch Box and the cables necessary to interconnect the electronics. Also included are game Overlays, Instruction Book, Poker Chips, etc., for playing the various games. Accessories such as the Rifle are available as options.

DMFWP274

The Master Control Unit consists of a master board and 12 solid-state plug-in modules. Figure 1 is the block diagram of the Odyssey system excluding the television set.

The Odyssey game is connected as shown in Figure 2. The Master Control Unit generates the video, sync and RF signals necessary to produce two Players, a Ball and a Wall on the television screen.

Printed in U.S.A., Copyright 1975




Figure 2 -- Odyssey Game Setup with Rifle Accessory

INSTALLATION INSTRUCTIONS

1. Plug the Player Control Unit cables into the Master Control Unit as illustrated in Figure 2. The two Player Control Units are identical; however, the Player Control Unit connected to the PLAYER 1 socket will be called Player Control Unit Number 1 and the one connected to the PLAYER 2 socket will be called Player Control Unit Number 2.
2. The GAME CORD is used to connect the Master Control Unit to the ANTENNA-GAME SWITCH. Insert one end of the GAME CORD into the socket marked GAME CORD on the Master Control Unit. The other end plugs into the socket on the top of the ANTENNA-GAME SWITCH marked GAME CORD.
3. The ANTENNA-GAME SWITCH is provided as a convenience to allow selection of either Odyssey or regular television viewing, without having to disturb antenna connections. After its initial installation, merely move the slide switch to either the GAME position for ODYSSEY . . . or to the TV position for television viewing.

Locate the VHF antenna terminals on the back of the television. Disconnect the VHF antenna cable (if there is one), and connect it to the ANTENNA-GAME SWITCH, as shown in the illustration. Connect the lead from the ANTENNA-GAME SWITCH to the VHF-300 terminals. When changing from GAME to TV, make certain the slide switch is moved to the extreme position; do not leave it in the middle.


Before proceeding further, set the ANTENNA-GAME SWITCH to the TV position and turn on television. Select a known operating channel and adjust television for normal picture viewing. If the TV incorporates a Remote System with Automatic Shut-Off, place the Remote Defeat Switch on the television in the "Off" position so the set does not turn off during testing.

Now, set the television to the VHF Channel (3 or 4) on which ODYSSEY will be displayed. Plug one end of the GAME CORD into the GAME CORD socket on the ANTENNA-GAME SWITCH and place the switch in the GAME position. Insert Game Card No. 1 for "Table Tennis" in the GAME CARD SLOT on the Master Control Unit and press down firmly until it is completely plugged in. The number 1 should be facing outward. The GAME CARD is also the power switch for the Master Control Unit so a signal is now being sent to the television receiver. It is, therefore, very important to remove the GAME CARD after playing, so that battery power is not depleted.


Look for a white vertical line from the top to bottom and possibly one or two small white squares. Adjust the VHF Fine Tuning on the television, if necessary, until this vertical line is straight and clear. Also, adjust the Brightness and Contrast controls for a bright white line against a dark gray background.

The CENTER CONTROL on the Master Control Unit should be adjusted until the vertical line is in the center of the television screen.

300 Ohm Lead-In



75 Ohm Coax Lead-In




701517-1 "ANTENNA GAME SWITCH BOX" REPLACEMENT PARTS LIST

REF.	DESCRIPTION	PART NO.
	Strain Relief Bushing	102635-3
	Plastic Hook (2 used)	142712-1
	Antenna Connector, Male Coax	180739-1
	Antenna Connector, Female Coax	180902-3
	Antenna Switch Box	731913-5
	Antenna Switch Cover	731914-2
S1	TV/Game Switch	160499-1
T1	Balun	361000-8
T2	Balun	361485-1

CHECKOUT PROCEDURE

1. Visually inspect Master Control Unit, Player Control Units, and cables for breakage, cracks, broken or bent connector pins, broken wires, foreign material, corrosion or other damage.
2. Check to insure batteries are correctly installed.
3. Following the installation instructions on Page 2 connect Odyssey to a good TV receiver. Check Channel Switch setting in Odyssey battery compartment. Insert Game Card No. 1 in the Master Control Unit.
4. If there is no player image on the television screen when a Game Card is inserted in the Master Control Unit:
 - a. Rotate the HORIZONTAL and VERTICAL controls on both Player Control Units. If the Player images do not appear on the screen, continue with the check list.
 - b. Check to see that the Channel Selector on television is set to the proper channel (3 or 4), as indicated by the Channel Switch in the Master Control Unit.
 - c. Check to see that the Game Card is inserted properly with the number facing outward and is plugged in all the way.
 - d. Check to see that the Antenna-Game Switch is in the "Game" position and that the Antenna-Game Switch has been properly installed.
 - e. Check to see that the Game Cord is plugged into the socket provided on the top of the Antenna-Game Switch and on the back of the Master Control Unit.
 - f. Connect an external +9 volt power supply to J1. If unit now functions normally, replace all batteries with new ones. Insure that batteries are properly installed.



- g. Check to insure that the contacts of J1 close when external power plug is removed. If J1 contacts do not press together, bend one or the other until contact is made. Recheck operation with external power supply. J1 is accessible through the battery compartment.
5. If trouble is experienced with one or more games:
 - a. Check to be sure the proper Game Card is properly inserted in the Master Control Unit.
 - b. Check Game Card to see if there is any visible damage to the card.
 - c. If no Players, Ball, or Wall appear on the television screen, try a new Game Card.
 - d. If one Player does not appear or cannot be controlled, or if control of Ball by that Player Control Unit is abnormal, unplug the Player Control Units and switch them. If malfunction changes to other side, a Player Control Unit is defective and should be replaced.
 - e. In the event the preceding steps fail to locate the problem, the Master Control Unit should be repaired or replaced.
 - f. If the Unit operates normally except with accessories, check accessory connections. Test the Unit with new accessory. If the malfunction disappears, original accessory is defective; if not, replace Master Control Unit.

"CIRCUIT MODULES" REPLACEMENT PARTS LIST
 (Individual Parts with the Module are not available)

REF.	DESCRIPTION	PART NO.
	Horizontal Sync Generator Module	703491-3
	Vertical Sync Generator Module (BLAK)	703492-3
	Vertical Sync Generator Module (BK12)	703492-5
	Player No. 1 Generator Module (BLAK)	703493-2
	Player No. 1 Generator Module (BK12)	703493-3
	Player No. 2 Generator Module (BLAK)	703493-2
	Player No. 2 Generator Module (BK12)	703493-3
	Ball Generator Module (BLAK)	703493-2

REF.	DESCRIPTION	PART NO.
	Ball Generator Module (BK12)	703493-3
	Wall Generator Module (BLAK)	703493-2
	Wall Generator Module (BK12)	703493-3
	Flip-Flop/English Module	703494-2
	Flip-Flop/Ball Module	703494-2
	Gate Matrix Module (BLAK)	703495-2
	Gate Matrix Module (BK12)	703495-4
	Summer Module	703496-2
	RF Oscillator Module	703497-3
	RF Filter Module	703498-2
	Hand Control No. 1 & 2 Module (BLAK)	703488-2
	Hand Control No. 1 & 2 Module (BK12)	703488-3

701578-1 & 4 "PLAYER CONTROL" REPLACEMENT PARTS LIST

REF.	DESCRIPTION	PART NO.	REF.	DESCRIPTION	PART NO.
	Vertical Knob	142695-1		Back Control Cover	142705-1
	Horizontal Knob	142696-1		Feet, Black (4 used)	141737-3
	English Knob	142697-4	S1	Reset Switch	160487-1
	Reset Switch Knob	142828-1	R6A,B	100K/25K, English/Horizontal	220272-3
	Front Control Cover	142706-1	R8	50K, Vertical	220281-1

"GAME BOX" REPLACEMENT PARTS LIST

REF.	DESCRIPTION	PART NO.	REF.	DESCRIPTION	PART NO.
	TABLE TENNIS Game Card	142888-1		SIMON SAYS Overlay (Medium)	151366-8
	Overlay (Medium)	151366-2		Overlay (Large)	151367-8
	Overlay (Large)	151367-2		Cards	701527-1
	SKI Game Card	142888-2		HAUNTED HOUSE Overlay (Medium)	151366-9
	Overlay (Medium)	151366-5		Overlay (Large)	151367-9
	Overlay (Large)	151367-5		ANOLOGIC Overlay (Medium)	151366-10
	HOCKEY Game Card	142888-3		Overlay (Large)	151367-10
	Overlay (Medium)	151366-3		CAT & MOUSE Overlay (Medium)	151366-12
	Overlay (Large)	151367-3		Overlay (Large)	151367-12
	Tape	642897-1		STATES Overlay (Medium)	151366-24
	FOOTBALL Game Card	142888-4		Overlay (Large)	151367-24
	Overlay (Medium)	151366-4		Map	591550-1
	Overlay (Large)	151367-4		Cards	701526-1
	Marker & Score Card	642964-1		Folder	591549-1
	Board	642898-1		MISCELLANEOUS	
	Cards	701525-1		Operating Instruction Booklet	1B2622-3
	SUBMARINE Game Card	142888-5		Battery (6 used)	530078-2
	Overlay (Medium)	151366-6		Dice (2 used)	143018-1
	Overlay (Large)	151367-6			
	ROULETTE Game Card	142888-6			
	Overlay (Medium)	151366-11			
	Overlay (Large)	151367-11			
	Chips	701528-1			

703490-4 & 5 "MASTER" BOARD REPLACEMENT PARTS LIST

REF.	DESCRIPTION	PART NO.	REF.	DESCRIPTION	PART NO.
	CAPACITORS				
C1	Electrolytic, 220 mfd., 10V	270111-2210	D7	Germanium Diode	530065-1002
C2	Electrolytic, 47 mfd., 16V	270109-5115	D8	Germanium Diode	530065-1002
C3	Electrolytic, 10 mfd., 35V	270109-1135	D9	Silicon Diode (BK12 only)	530072-1018
C4	Electrolytic, 47 mfd., 16V	270111-5115	D10	Silicon Diode (BK12 Only)	530072-1018
C5	Electrolytic, 10 mfd., 35V	270109-1135	Z1	Zener Diode (6.2V) (BLAK Only)	530157-629
C6	Electrolytic, 100 mfd., 10V	270109-1210	Z1	Zener Diode (6.8V) (BK12 Only)	530157-689
C7	Electrolytic, 10 mfd., 35V	270109-1135	Z2	Zener Diode (6.8V) (BLAK Only)	530157-689
C8	Electrolytic, 4.7 mfd., 50V	270109-5050	Q1	NPN Silicon	610142-9
C9	Electrolytic, 10 mfd., 35V	270109-1135	Q2	NPN Silicon	610142-9
C10	Electrolytic, 4.7 mfd., 50V	270109-5050	Q3	NPN Silicon (BK12 Only)	610142-9
C12	Electrolytic, 100 mfd., 10V	270109-1210	SCR1	Thyristor	611003-1
C14	Electrolytic, 470 mfd., 16V	270109-5215		MISCELLANEOUS	
C15	Electrolytic, 470 mfd., 16V	270109-5215			
C21	Electrolytic, 47 mfd., 16V (BK12 only)	270109-5115	FB1 thru 4	Ferrite Bead	364005-1
	CONTROLS & SWITCHES		TM1	Thermistor (BLAK Only)	230205-1
R3	9K, Ball Speed	220166-44	TM2	Thermistor (BLAK Only)	230205-2
R4	15K, Ball Height	220316-1533	J1	AC/DC Power Assembly	701479-4
R6	47K, Ball Width	220316-4733		- Battery Connector	181096-1
R12	25K, Wall Center Adjust	220311-3		- Jack	181102-1
R17	47K, Wall Width	220317-4732	J2	- Terminals (2 used)	200451-2
R26	47K, Player No. 1 Width	220316-4733	J3	Edge Board Connector	181105-3
R28	15K, Player No. 1 Height	220316-1533	J4	12 Pin Female HSG Molex (Hand Control No. 2)	180727-2
R31	15K, Player No. 2 Height	220316-1533		12 Pin Female HSG Molex (Hand Control No. 1)	180727-2
R32	47K, Player No. 2 Width	220316-4733	J5 thru	Module Socket	181069-1
R38	47K, Horiz. Frequency Adjust	220300-4732	J12		
R39	100K, Vertical Freq. Adjust	220316-1043	J15 thru	Module Socket	181069-1
S1	Channel Slide Switch	160498-1	J17	Module Socket	181069-1
	SEMICONDUCTORS		J18	Module Socket (RF Filter)	181069-2
D2	Silicon Diode	530072-1018	J19	Phono Coax Socket	180902-4
D3	Silicon Diode	530072-1018	J20	6 Pin Female HSG Molex (Rifle)	180732-1
D4	Silicon Diode	530072-1018		RF Shield Top	731906-1
D5	Germanium Diode	530065-1002		RF Shield, Bottom	731907-1
D6	Germanium Diode	530065-1002		RF Shield, Side	731908-1
				RF Spacer	642940-1
				AC External Adaptor (Optional Accessory)	2A9179






Figure 3 -- Master Board Module Location



GAME CARD INTERCONNECTIONS

NUMBERS JOINED BY A HYPHEN (-) ARE CONNECTED ON GAME CARD PC BOARD. A SEMICOLON (;) SEPARATES EACH SERIES FROM THE NEXT SERIES. IF A PIN NUMBER IS NOT SHOWN, THERE IS NO CONNECTION AT THAT PIN.

- GAME CARD 1
2-4; 6-8-14-16-20-22; 30-34; 31-39; 35-37.
- GAME CARD 2
2-4; 6-8.
- GAME CARD 3
2-4; 6-8-10-20-22; 30-34; 31-39; 35-37; 42-44.
- GAME CARD 4
2-4; 6-8-18; 33-37-39.
- GAME CARD 5
2-4; 6-8-10-20-22; 21-23-25; 30-34; 31-33-39; 35-37.
- GAME CARD 6
2-4; 3-5-9; 26-28-38.
- GAME CARD 7
2-4; 6-8-10-14-16-20-22; 13-27; 23-25; 30-34; 31-39; 35-37; 42-44.
- GAME CARD 8
2-4; 6-8-12-14-20-22; 9-11-13; 15-17; 31-39; 34-36; 35-37.
- GAME CARD 9
2-4; 6-24; 21-23.
- GAME CARD 10
2-4; 6-8-10-20-22-24; 23-25; 30-34; 31-39; 35-37.


703490		
	RUN 1	RUN 2
R37	10K	JUMPER
R22	6.8K	3.9K
R23	68K	27K

703492		
	RUN 1	RUN 2
R2	180K	CF 180K
R5	300K	CF 300K



703491		
	RUN 1	RUN 2
R2	130K	CF 150K
R4	1.5K	CF 3.3K
R5	150K	CF 300K

703497		
	RUN 1	RUN 2
C7	10 PF	12 PF
R5	4.7K	15K
C2	100 PF	47 PF
SHIELD	OMT	USE


703498		
	RUN 1	RUN 2
C2	47 PF	JUMPER
C5	27 PF	22 PF
C7	100 PF	JUMPER




OPTIONAL ACCESSORY
MODEL 2A9179
EXT POWER
ADAPTOR




1TL200 BLAK ODYSSEY SCHEMATIC DIAGRAM







- NOTES
UNLESS OTHERWISE SPECIFIED
1. CAPACITANCE VALUES 1 OR GREATER ARE IN PICO FARADS.
 2. CAPACITANCE VALUES LESS THAN 1 ARE IN MICRO FARADS.
 3. RESISTORS ARE 1/4 WATT, 10%.
 4. Δ = ADD JUMPERS WHERE PARTS INDICATED.
 5. * = SPACE PROVIDED ON LAYOUT, NO JUMPER.
 6. DIODES IN CIRCLES ARE GERMANIUM, OTHERS ARE SILICON.
 7. VOLTAGE READINGS TAKEN WITH CARD/ UNLESS OTHERWISE NOTED.
 8. VOLTAGE READINGS TAKEN WITH FLUKE DIGITAL VOLTMETER #8100 A.



1TL200BK12 ODYSSEY SCHEMATIC DIAGRAM





This troubleshooting guide contains instructions for locating improper adjustments, or faulty modules. The symptoms are followed with the items most likely to be the cause. Figure 1 and Figure 3 may provide helpful information.

Before making any adjustments or changing modules, inspect the chassis to insure all modules are secure in their respective sockets and no mechanical damage is apparent. Connect Odyssey to a TV set using the complete installation procedure previously outlined. Insert Game Card No. 1 and measure the +5.6 VDC on BLAK versions, (+6.2 VDC on BK12 versions) regulated supply voltage at TP1. If the voltage at W1 is less than 7.5 Volts, replace the batteries.

The spot generator modules used for generation of Player 1, Player 2, Ball, and Wall are identical and may be interchanged as an aid to troubleshooting. Similarly the ball flip-flop and English flip-flop use the same module.

1. **Player, Ball, or Wall is too wide or too narrow.**
 - a. Width control R26, R32, R6, or R17 is set improperly.
 - b. Applicable spot generator module is defective.
2. **Player or Ball is too short or too tall.**
 - a. Height control R28, R31, or R4 is set improperly.
 - b. Applicable spot generator module is defective.
3. **Display has vertical roll (may appear as multiple random spots on screen).**
 - a. Vertical frequency control R39 is set improperly.
 - b. Vertical sync generator module is defective.
4. **Display tears horizontally.**
 - a. Horizontal frequency control R38 is set improperly.
 - b. Horizontal sync generator module is defective.
5. **Player No. 1 does not appear on screen.**
 - a. R26 (Width) or R28 (Height) controls set too low.
 - b. Player 1 spot generator module is defective.
 - c. Q1 or SCR 1 in crowbar circuit is defective.
6. **Player No. 2 does not appear on screen.**
 - a. R32 (Width) or R31 (Height) controls set too low.
 - b. Player 2 spot generator module is defective.
 - c. Q2 or SCR1 in crowbar circuit is defective.
7. **Ball does not appear on screen.**
 - a. R6 (Width) or R4 (Height) controls set too low.

- b. Ball spot generator module is defective.
- c. English flip-flop module is defective.
- d. Ball flip-flop module is defective.
- e. Gate matrix module is defective.
- f. Q2 or SCR1 in crowbar circuit is defective.

8. **Wall does not appear on screen.**

- a. R17 Wall Width control is set too low.
- b. Wall spot generator is defective.

9. **No video appears on screen.**

- a. TV may be on wrong channel.
- b. TV may be mistuned.
- c. Antenna-Game Switch not in Game position.
- d. Game Cord is open or shorted.
- e. Antenna-Game Switch is defective.
- f. Q1 voltage regulator is defective.
- g. Horizontal sync generator module is defective.
- h. Vertical sync generator module is defective.
- i. Summer module is defective.
- j. Master board containing RF circuits is defective.

NOTE: IF RF CIRCUITS ARE DEFECTIVE REPLACE THE MODULES AND RETURN TO FACTORY. ALSO WHEN REPLACING MODULES BE SURE TO RESOLDER THE RF SHIELD COVER.

10. **Ball movement is erratic or drifts slowly.**

- a. English flip-flop module is defective.
- b. Ball flip-flop module is defective.
- c. Ball spot generator is defective.

11. **Wall only appears on screen, no players or Ball.**

- a. Vertical sync generator is defective.

12. **At coincidence, Player or Ball does not disappear.**

- a. Gate matrix is defective.
- b. Q2 or SCR1 in crowbar circuit is defective.

13. **Player is not moveable over entire face of TV screen.**

- a. Player Control Unit is defective.
- b. Player spot generator module is defective.

General Des

The rifle is designed to be inserted into the Ma all light so (lamps and viewing cor

NOTE: If that which brightened

Sight Align

1. Set INST
2. Plug recep

3. Insert a whi cock toward light Verti the c

4. Stand aim t

5. Squee Thus conti while

6. If air of th or co

7. If th on th of err

8. Once of yo TV se

9. Aim screen turn contr the se

LDR Bias A

1. Deta remo toget

2. Repla half c

3. Insur tilted

General Description

The rifle is sturdily constructed and is completely safe. It is designed to extinguish a light (or target) that appears on the TV screen when either Game Card 9 or 10 is inserted into the Master Control Unit. Since the rifle is sensitive to all light sources, it is important that the room lighting (lamps and sunlight) be adjusted to simulate normal light viewing conditions.

NOTE: If the rifle is aimed at a light source other than that which appears on the screen (such as a lamp or sun-brightened window), it will extinguish the target.

Sight Alignment

1. Set up your ODYSSEY unit as outlined in the INSTALLATION instructions.
2. Plug the rifle cord (P20) into the ACC (Accessory) receptacle on the back of the Master Control unit.
3. Insert Game Card 9 into the Master Control unit. If a white spot of light is not visible on the TV screen, cock the rifle by sliding the pump handle back towards the trigger and then releasing it. Should the light still not be visible, rotate the Player No. 2 Vertical and Horizontal controls until the light is in the center of the screen.
4. Stand approximately six feet from the TV screen and aim the rifle at the spot of light.
5. Squeeze the trigger, the spot of light should disappear. Thus the sights are okay. If the light does not disappear, continue cocking the rifle and pulling the trigger while moving closer to the screen.
6. If aim is off in elevation, turn the screw adjustment of the rear sight. (Rotate clockwise to lower muzzle or counterclockwise to raise muzzle).
7. If the aim is off in azimuth, loosen the clamp screw on the front sight and rotate the sight in the direction of error.
8. Once you have extinguished the light and are certain of your aim, return to a position of six feet from the TV screen and cock the rifle to reset the target.
9. Aim the rifle at each of the four corners of the screen and pull the trigger. If the target disappears, turn the brightness control of the TV down and the contrast control Up. This will lower the light level of the screen background and brighten the target.

LDR Bias Adjustment

1. Detach the left half of the stock of the rifle by removing the five screws holding the two halves together.
2. Replace the two screws through the barrel and right half of the stock to hold it while testing.
3. Insure that the barrel lens is in place, clean and not tilted.



4. Plug the rifle cord (P20) into the ACC jack on the Master Control unit.
5. Insert Game Card 9 into the slot.
6. Locate Player No. 2 on the screen.
7. Rotate the brightness control of the TV until the background level is a natural gray.
8. Rotate the LDR Bias Adjust (R11) fully clockwise.
9. Aim the gun point blank at the gray area (not at the Spot) and pull the trigger. The Player No. 2 Spot should remain lit.
10. While pumping the trigger, slowly rotate (R11) counterclockwise until Player No. 2 spot disappears. (Note: allow at least 2 seconds between triggering). If the spot never disappears at any setting of R11, replace the gun.
11. Press the Player No. 2 reset button.
12. Adjust the TV brightness and contrast controls for a white Player No. 2 spot on a dark background.
13. To check for correct LDR Bias adjustment, simulate ambient light surroundings.
14. Hold the gun six feet from the TV, aim at the background and pull the trigger. The spot should remain lit.
15. Carefully aim at the spot and pull the trigger. The spot now should disappear.

Rifle Troubleshooting

1. Target does not disappear when lit.
 - a. Check the lens in the end of the barrel for dirt or scratches.
 - b. Make sure lens is not tilted. (Replace lens if necessary).
 - c. Check accuracy of gun sights. (Adjust sights as required).
 - d. Perform LDR Bias adjustment.
 - e. Rifle is defective.
 - f. Master Control unit is defective.
2. Target disappears even when missed.
 - a. Correct setting of the brightness and contrast controls on TV. (Brightness turned down and Contrast Up).
 - b. Perform LDR Bias adjustment.
 - c. Rifle is defective.
 - d. Master Control unit is defective.




REF.
C1
C2
C3
R11
S1
S2



Rifle Sights

1TL950 RIFLE SCHEMATIC DIAGRAM



703520-1 "RIFLETRONIX BOARD" REPLACEMENT PARTS LIST

REF.	DESCRIPTION	PART NO.	REF.	DESCRIPTION	PART NO.
CAPACITORS			SEMICONDUCTORS		
C1	Electrolytic, 47 mfd., 16V	270109-5115	Q1	NPN Silicon	610113-1
C2	Polyester, .047 mfd., 10%, 100V	250581-4743	Q2	NPN Silicon	610142-9
C3	Electrolytic, 4.7 mfd., 50V	270109-5050	Q3	NPN Silicon	610142-5
CONTROLS & SWITCHES			MISCELLANEOUS		
R11	1 meg., LDR Bias Adjust	220193-36	LDR1	Light Dependent Resistor	230204-2
S1	Trigger Switch	731984-1		LDR Holder, Top	142722-1
S2	Reset Switch	731985-1		LDR Holder, Bottom	142723-1
				Wire Wrap Pin	200460-3