



# COURIER HST™

---

# MODEM

9600/2400/1200/300 BPS, AUTO DIAL, AUTO ANSWER MODEM  
WITH USR HST™ ERROR CONTROL

# USER'S MANUAL

**USRobotics**

**COURIER HST™**

**MODEM**

9600/2400/1200/300 BPS, AUTO DIAL, AUTO ANSWER MODEM  
WITH USR HST™ ERROR CONTROL

# USER'S MANUAL

Courier HST is a trademark of USRobotics, Inc. Touch-Tone and Digital Data Service (DDS) are trademarks of American Telephone and Telegraph. MCI Mail is a service mark of MCI Communications, Incorporated. Microcom Networking Protocol (MNP) is a trademark of Microcom, Inc. Sprint is a trademark of General Telephone and Electric.

Limited Warranty	vii
FCC Registration	viii
Connecting to the Telephone Company	viii
Radio and Television Interference	ix
For Canadian Modem Users	x
How to Use this Manual	xi

## PART I. INSTALLATION AND OPERATION

CHAPTER 1—Introduction	1-1
USR-HST	
Trellis Coded Modulation	1-1
Asymmetric Modulation	1-1
Enhanced Error Control	1-1
Shorter Response Time	1-1
The Courier Product Family	1-1
Courier HST Compatibility	1-3
CHAPTER 2—Set-Up and Testing	2-1
Package Components	2-1
Operational Requirements	2-1
Assembling the Modem	2-2
Testing	2-5
Analog Loopback Self-Test	2-6
Additional Test Procedures	2-7
CHAPTER 3—Operations at a Glance	3-1
Data Format	3-1
Error Control	3-1
Dialing	3-1
HST-Compatible, 9600 bps	3-1
MNP-Compatible, 2400 or 1200 bps	3-1
Non-MNP Compatible, 2400, 1200, 300 bps	3-2
Flow Control	3-2
Maximum Throughput	3-2
High-Speed Channel Turnaround	3-2
Link Negotiation	3-2
Data Rate Defaults	3-3
Nonvolatile Memory (NRAM)	3-3
Phone Number Storage	3-3
Dialing Stored Numbers	3-3

Busy Answer	3-4
Inactivity Timer	3-4
CHAPTER 4—Interface Controls	4-1
Terminology	4-1
Error Control	4-1
ARQ Retry Timer	4-1
Error Control Modes (&Mn)	4-2
With Auto Answer	4-2
Flow Control Commands	4-2
Transmit Data Flow Control (&Hn)	4-3
Received Data Flow Control	4-4
Software Control (&In)	4-4
Hardware Control (&Rn)	4-5
Data Rate Commands	4-5
Optional Fixed Rates	4-5
Terminal Rate Select (&Bn)	4-6
Link Rate Select (&Nn)	4-6
Rate-Select Guidelines	4-6
DSR Override (&Sn)	4-7
CHAPTER 5—Internal Controls	5-1
Setting/Using Defaults	5-1
Writing Defaults to NRAM (&W)	5-1
Loading the Factory Defaults (&F)	5-2
Resetting to NRAM Defaults (Z)	5-2
Storing Telephone Numbers (&Zn = s)	5-2
Result Codes	5-3
Response Modes (Vn)	5-3
Result Code Sets (Xn)	5-3
Result Codes Options Table	5-4
Options Summary	5-4
Quiet Mode (Qn)	5-5
/ARQ Result Codes (&An)	5-5
Local Echo	5-5
Command Mode Local Echo (En)	5-5
Online Local Echo (Fn)	5-6
The Audio Monitor	5-6
Speaker Control (Mn)	5-6
Modem Clock Usage (Kn)	5-7
Transmitter Enable/Disable (Cn)	5-7
Break Handling (&Yn)	5-8
The S-Registers	5-8

CHAPTER 6—Dialing and Answering	6-1
Basic Requirements	6-1
Transmission Rate	6-1
Error Control	6-1
Automatic Retrain	6-2
Placing Calls	6-2
Dial (D)	6-2
Dialing Type (T, P)	6-2
Adaptive Dialing	6-3
Pause (,)	6-3
Dial and Return to Command Mode (;)	6-4
Dialing Letters (‘‘)	6-5
Transferring Calls (!)	6-5
Wait for a Second Dial Tone (W)	6-5
Wait for an Answer (@)	6-6
Reversing Originate/Answer Frequencies	6-6
Canceling Dialing	6-6
Redialing	6-7
Reexecute the Last Command (A/)	6-7
Automated Redialing	6-7
Continuous Repeat (>)	6-7
Continuous Reexecute (A>)	6-7
Exiting Repeat Mode	6-7
Dialing a Stored Number (DS <i>n</i> )	6-8
Pulse Dial Make/Break Ratio (&P <i>n</i> )	6-8
Escape Code Operations (+ + +)	6-8
ARQ Mode Response	6-9
Normal Mode Responses	6-9
Returning Online (O)	6-9
Hanging UP (H <i>n</i> )	6-10
Automatic Answering	6-10
Suppressing Auto Answer	6-10
Points to Remember	6-10
U.S./CCITT Answer Tone (B <i>n</i> )	6-11
CHAPTER 7—Queries and Help Screens	7-1
User Inquiries (I <i>n</i> )	7-1
S-Register Query (S <i>r</i> ?)	7-3
S17	7-3
S20	7-3

Phone Number Query (&Zn?)	7-4
Help Screens	7-4
Basic Command Set (\$)	7-4
Extended Command Set (&\$)	7-5
S-Register Functions (\$\$)	7-5
Dialing (D\$)	7-6

## PART II. REFERENCE

APPENDIX A—Error/Flow Control Concepts	A-1
Overview	A-1
Throughput	A-1
MNP Service Classes	A-1
Error Detection/Retransmission	A-2
Flow Control	A-3
Example 1—Transmit Data	A-4
Example 2—Received Data	A-4
APPENDIX B—Summaries and Tables	B-1
The RS-232C Interface, with Pin Definitions	B-1.1
Front End Indicators	B-2.1
DIP Switch Summary	B-3.1
Default Settings	B-4.1
S-Register Summary	B-5.1
ASCII Chart	B-6.1
APPENDIX C—Alphabetical Command Summary	C-1
APPENDIX D—Problems and Solutions	D-1
If You Still Have Problems	D-3
APPENDIX E—Additional Operational Information	E-1
Using Both Voice and Data Communications	E-1.1
High Speed/Low Speed Protocol	E-2.1
Retrain Sequence	E-3.1
PBX, Dedicated Line, and Leased Line Operations	E-4.1
Hewlett Packard Installations	E-5.1
APPENDIX F—Technical Specifications	F-1
GLOSSARY	G-1
INDEX	

**LIMITED  
WARRANTY**

U.S. Robotics, Inc., warrants to the original consumer or other end user purchaser that this product is free from defects in materials or workmanship for a period of two years from the date of purchase. During the warranty period, and upon proof of purchase, the product will be repaired or replaced (with the same or similar model) at our option, without charge for either parts or labor. This warranty shall not apply if the product is modified, tampered with, misused, or subjected to abnormal working conditions.

---

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE OR PURPOSE, AND U.S. ROBOTICS SHALL IN NO EVENT BE LIABLE TO PURCHASER FOR INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND OR CHARACTER.

---

Some states do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

To obtain service under this warranty, contact the U.S. Robotics Technical Support Department at 800/982-5151 (in Illinois, 312/982-5151), or by mail at 8100 North McCormick Blvd., Skokie, Illinois, 60076. You will be given a Return Materials Authorization (RMA) number to help us keep track of your warranty request. Once you have received your RMA number, take or mail the product, postage prepaid, to U.S. Robotics at the above address. Include proof of the date of purchase. **IMPORTANT:** If you ship your unit, pack it securely, be sure your RMA number is visible on the outside of the package, and ship it charges prepaid and insured.

- Should you encounter problems in operating this device, follow the instructions in Appendix D in Part II of this manual. The Appendix contains solutions to operating problems as well as procedures to follow if there is an apparent modem malfunction.

FCC  
REGISTRATION

FCC68: CJE794-11323-DM-E  
RINGER EQUIVALENCE: 0.4B  
FCC15: CJE794FAST

CONNECTING  
TO THE  
TELEPHONE  
COMPANY

It is not necessary to notify the telephone company before installing the modem. However, the telephone company may request the telephone number(s) to which the Courier is connected and the FCC information printed above.

If the telephone company has any questions or raises problems, ask them to call the Technical Support Department, USRobotics, Inc., 800/982-5151 (in Illinois, 312/982-5151).

If the modem is malfunctioning, it may affect the telephone lines. In this case, disconnect the modem until the source of the difficulty is traced. Do not use the modem on party or coin telephone lines.

RADIO AND  
TELEVISION  
INTERFERENCE

This equipment generates and uses radio frequency energy and if not installed and used properly, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. The Courier HST has been tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference in a residential installation.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause interference to radio or television reception, which you can determine by monitoring reception when the modem is on and off, try to correct the problem with one or more of the following measures.

- Reorient the receiving antenna.

- Relocate the computer with respect to the receiver.

- Relocate the computer and/or the receiver so that they are on separate branch circuits.

If necessary, consult your dealer or an experienced radio/television technician for additional suggestions. You may find the following booklet, prepared by the Federal Communications Commission, helpful:

- How to Identify and Resolve Radio-TV Interference Problems

- Stock No. 004-000-0345-4

- U.S. Government Printing Office

- Washington, DC 20402

### FOR CANADIAN MODEM USERS

The Canadian Department of Communications (DOC) label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational, and safety requirements. The department does not guarantee the equipment will operate to a user's satisfaction.

Before installing this equipment, make sure you are permitted to connect it to the facilities of the local telecommunications company. You must also install the equipment using an acceptable method of connection. In some cases, you may also extend the company's inside wiring for single line individual service by means of a certified connector assembly (telephone extension cord). You should be aware, however, that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by a user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

For your own protection, make sure that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**CAUTION:** Do not attempt to make such connections yourself; contact the appropriate electric inspection authority or electrician.

#### Courier HST Modem Load Number: 38B

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load to be connected to the telephone loop used by the device, without overloading. The termination on a loop may consist of any combination of devices, subject only to the requirement that the total of the Load Numbers of all the devices not exceed 100. An alphabetic suffix is also specified in the Load Number for the appropriate ringing type (A or B), if applicable. For example, LN = 38B designates a Load Number of 38 and a B-type ringer.

## HOW TO USE THIS MANUAL

This manual is divided into two parts. The first part is designed to aid you in getting your modem connected and operating as quickly as possible. Part I also includes chapters on command usage. Part II contains a number of informative appendixes that you may or may not need, depending on your situation, plus a Glossary and Index.

Below is a brief description of the manual's contents. We suggest you review at least Chapters 1-3 before operating the modem.

- Chapter 1—Introduction
- Chapter 2—Assembling and testing the modem
- Chapter 3—Immediate operations—essentials
- Chapter 4—Interface controls
- Chapter 5—Internal controls
- Chapter 6—Calling, answering and disconnecting
- Chapter 7—Inquiries and Help screens

The appendixes in Part II cover the following subjects:

- Background information on error and flow control
- Summaries and tables
- Problems, their causes, and solutions
- Additional operational information
- Technical specifications

Whenever a cross-reference is made to the same or a similar subject, you'll be directed to the appropriate section of the manual with this arrowhead symbol, ►



**USR-HST**

The USRobotics Courier HST modem represents powerful, advanced electronic design that gives you optimal speed and accuracy. USRobotics' High Speed Technology (USR-HST) offers these advantages:

**Trellis Coded Modulation**

Trellis coded modulation is a convolutional coding technique that makes data transmission less vulnerable to errors caused by phone network impairments. It can tolerate twice the telephone channel noise power as conventional modulation (quadrature amplitude modulation, or QAM), so there are fewer error-control retransmissions. Trellis coded modulation is also less susceptible to impulse-type noise.

**Asymmetric Modulation**

At top speed, data flows in one direction at 9600 bits per second and at 300 bits per second in the other. The modems automatically switch the high-speed channel on demand, i.e., depending on which transmitter has the most data to transmit. In practice, the modems seldom need to reverse channels, since the asymmetric design reflects typical communications sessions—brief messages typed at one end of the link, files sent from the other. The asymmetric approach provides the most efficient and economical strategy for using ordinary phone channels at high speeds.

**Enhanced Error Control**

The HST error control protocol uses sophisticated error detection methods to ensure data integrity. Design efficiencies have reduced the overhead (extra control information) experienced with error control protocols at lower speeds. On local and long-distance connections the result is accuracy, greater speed and higher throughput—approximately 1100 characters per second.

**Shorter Response Time**

9600-bps modems are generally most efficient for file transfers. You'll find that the Courier HST also offers faster response times during interactive sessions.

**THE COURIER  
PRODUCT  
FAMILY**

In addition to the Courier HST's new features, the modem incorporates the same popular capabilities of other products in the Courier line:

**MNP Error Control at 2400/1200 BPS**

The Courier HST implements the Microcom Networking Protocol (MNP), Service Classes 1, 2, and 3, at 2400 and 1200 bits per second. This ensures compatibility with the Courier 2400e and other MNP-compatible modems at those speeds.

Data Rate Fallback	The Courier HST automatically falls back to 2400, 1200, and 300 bits per second, in both Originate and Answer Modes, to match a lower rate of a called or calling modem. You can optionally set local interface and link rates at fixed speeds.
Inactivity Timer	You can set the modem to automatically hang up after a specified number of minutes if there is no activity on the phone line.
Call Duration Reporting	The modem records the duration of your calls in hours, minutes, and seconds. This feature enables you to display and print an audit of your calling activities. You can optionally use the modem clock as a real-time clock.
Call Progress Detection	An optional set of result codes (screen messages) lets you know when a line is busy, a person rather than a modem has answered the phone, there is no dial tone, or the distant phone is ringing.
Modem Settings Display	On command, the modem displays its current settings, a handy way to check your transmission rate, S-registers and other operational controls.
HELP Screens	You can also display screens that summarize the command sets, Dial command options, and S-register functions.
Bottom Panel Reference	Operational summaries and other information are printed on the bottom of the modem case. A Dual In-Line Package (DIP) switch guide makes it easy to tailor the switch settings to your requirements.
Repeat Commands	You can have the modem continuously repeat a command until you instruct it otherwise. This is especially useful in dialing services whose lines are often busy.
Quote Mode	Set the modem to Quote Mode if you want it to dial an alphabetic "number," such as 800-"DIAL USR" (USRobotics' Sales Department).
Adaptive Dialing	You can set the modem to first try Touch-Tone dialing. If tone dialing doesn't work on the line, the modem automatically switches to the slower type, pulse (rotary).
Automatic Retraining	Retraining (a resynchronization with the remote modem) occurs if the modem detects line disturbances that might affect data reliability. At 9600 bps the connection must be with an HST-compatible modem. Retraining also occurs at

COURIER HST  
COMPATIBILITY

2400 bps if the other modem is *V.22bis*-compatible. (► Appendix E-3 contains more information.)


The Courier HST offers upgrading to 9600 bps while maintaining compatibility with most installed 2400/1200/300 bps, dial-up modems and existing software. Its compatibility features include the following:

- Can be used with any computer or terminal that is compatible with the RS-232C standard interface. (► For more information on the RS-232C interface, see Appendix B-1.)
- Can be used with any computer or terminal that uses ASCII, the standard character code supported by most equipment manufacturers.
- Connects with any modem whose signal scheme is compatible with the following standards at the given data rate:

300 bps	Bell 103
1200 bps	Bell 212A
2400 bps	<i>V.22bis</i>
9600 bps	USR-HST

- Uses the HST error control protocol at 9600 bps and, optionally, the MNP error control protocol, Service Classes 1, 2 and 3 at 2400/1200 bps.
- Is fully FCC-certified for the uses described in this manual.





**Figure 2.1—Courier HST**

### PACKAGE COMPONENTS

The box containing your Courier HST contains the following items in addition to this manual:

- The Courier HST modem
- An RJ11C phone cord
- A power adapter
- A Quick-Reference card, in the manual
- Your warranty card, to be filled out and returned to USRobotics, Inc.

### OPERATIONAL REQUIREMENTS

The Courier HST has minimal operational requirements. Be sure to read the information in the front of this manual about radio and television interference and connecting to the phone company. In addition, you should be aware of the following:

- Follow the operating instructions in Appendix E-4 if the modem is to be used in either of the following types of installation.
  - 1) The modem will be installed in a key system PBX in which RJ12 or RJ13 telephone jacks are used rather than the RJ11 jack.
  - 2) The modem will be attached to a user-installed phone line or a line leased from the telephone company. Often referred to as "dedicated" or "private," this type of line is used for a direct,


continuous connection between two modems. The connection is made without dialing.

- If the modem is installed in a Hewlett Packard system, be sure to follow the instructions in Appendix E-5.
- If you're working with a computer rather than a terminal, the computer must be in Terminal Mode. If you're not familiar with this requirement, check the Glossary and refer to your communications software documentation for instructions.
- You'll need an RS-232C cable to connect the modem to your computer or terminal. It should be a *shielded cable* to ensure minimal interference with radio and television reception. (► For information on the RS-232C interface, see Appendix B-1.)

The modem takes a DB-25P (25-pin plug) connector, but computer equipment varies: check the serial port at the rear of your machine. The port will be labeled "Modem," "Communications," or "EIA," or with a phone symbol. (Don't use the port marked "Printer" or "Aux.") If the port is a plug, specify a DB-25S (socket) connector to your dealer. If the port is a socket, specify a DB-25P (plug) connector. If your machine has other than a 25-pin port, check your documentation to see what type of RS-232C connector is required.


### ASSEMBLING THE MODEM

1. Turn off the computer or terminal and its peripheral devices.
2. Examine the label on the bottom of the modem. In addition to the summaries and other information, the label contains icons to aid in modem assembly. Then check the interfaces at the back of the modem, shown in the following photograph.



**Figure 2.2—Interface End, Courier HST**

3. Now review the attached interfaces in Figure 2.3.



**Figure 2.3—Connected Courier HST**


4. Check to make sure that the power switch is OFF; press it towards the zero in the I/O icon on the bottom label. Then plug the small end of the power supply cord into the power jack at the back of the modem, and plug the power adapter into a standard 115-volts AC wall socket.

Disconnect your present phone cable from the wall jack. Plug one end of the phone cord that came with the modem into the wall jack, and the other end into one of the phone jacks at the rear of the modem.

**NOTE:** Older telephone installations may not have the appropriate modular wall jack and plug. Adapters and RJ11C connectors are available from your telephone company or computer dealer.

If you want to keep your telephone connected for conventional calls, plug its cord into the other jack at the rear of the modem. You can also use both your telephone and modem in one call, although not at the same time. ► Appendix E-1, “Using Both Voice and Data Communications,” explains how to switch control of the phone line between the modem and the phone.

5. Next, check the positions of the bank of Dual In-Line Package (DIP) Switches located at the back of the modem. These switches are set at the factory to the positions desired by most users, as shown in Figure 2.4.



**Figure 2.4—DIP Switch Factory Settings**

► Use the guide on the bottom of the modem or refer to the more detailed summary in Appendix B-4 to determine if your situation requires a different setting. If you’re connecting the modem to a dedicated line or to a small interoffice or PBX system, review Appendix E-4 for special installation and operating instructions.

6. The final step is to connect the modem to the computer’s or terminal’s serial port with the RS-232C cable described earlier under “Operational Requirements.” Attach the appropriate connectors to the modem and to the serial port.

**NOTE:** When you are using the modem, be sure not to cover the vents on the top of the case.

The modem is now ready to be tested and operated.

**TESTING**

To verify that your modem is working properly, follow these steps:

1. Turn on your computer or terminal and clear the screen. Then turn the Courier's power switch ON. These front indicator LEDs will light up:
  - HS High speed: 9600 bits per second
  - CD Carrier Detect (if you haven't changed the factory setting of DIP switch 6)
  - TR Data Terminal Ready (if you haven't changed the factory setting of DIP switch 1)
  - MR Modem Ready/Power
  - RS Request to Send, if your computer/terminal supports RTS on the RS-232C interface
  - CS Clear to Send
2. If you're using a personal computer, load your telecommunications software and put your computer in Terminal Mode. This causes the computer to function as a terminal rather than a processor: everything you type at the keyboard goes directly to the modem. If necessary, refer to your communications software documentation for instructions.
3. Next, check to see if your machine and modem are communicating with each other by entering the command to get the modem's "attention." (Type either upper or lower case letters, not a combination. In this manual, the Carriage Return or Enter key required to issue commands is represented by the symbol <cr>. Don't type the angle brackets.)

Type the following:

**AT <cr>**

If everything is correct, the modem responds as follows:

**OK**

**NOTE:** The AT command is used alone to check the modem/terminal interface. AT is also the mandatory prefix for all other commands except A/ and A>, used to repeat execution of the command in the command buffer, and + + +, the escape code. These exceptions are explained in Chapter 6.

4. The modem is shipped with DIP switch 4 UP, causing the modem to display (echo) your keyboard commands. If your typed command is not displayed, your local echo is OFF. To turn the local echo ON, send the modem the following command.

```
ATE1 <cr>
```

If double characters appear on the screen, both your modem and software are set to local echo ON. Either set your software to local echo OFF, or turn the modem's echo OFF with this command:

```
ATE0 <cr>
```

5. If no OK appears on your screen, check out the connections at the interface end of the modem. Then carefully review the previous instructions to see if you've missed something.

### Analog Loopback Self-Test

Another way to verify that the modem is working properly is to run this test. During Analog Loopback the modem modulates and demodulates data sent to it, and returns the data to the screen. Follow these steps:

1. Because modulation at 9600 bps is asymmetric, the self-test must be performed at 2400 bps and below. The first step is to set your terminal or software to 2400 bps.
2. The modem's default error control setting is &M4. But if the modem is set for error control (&M4 or &M5) you won't be able to tell if there is a problem with the modem's transmitter or receiver, as it will retransmit any errored data. For this reason, the following command sets the modem to Normal Mode (&M0) before issuing the command for the test (S16=5D).

The test option causes the modem to modulate and demodulate its internal test pattern at the Originate (dial) frequency and return the pattern to the screen. (Spaces in commands are unnecessary, but are included in this manual for readability.) Type:

```
AT &M0 S16=5D <cr>
```

When the modem enters Analog Loopback Mode the AL indicator at the front of the modem lights. The modem goes *off hook* (the equivalent of picking up a phone

receiver), sends the message CONNECT 2400 to the screen, and then sends the test pattern.

3. Press any character key to terminate the test. The modem goes back *on hook* (the equivalent of hanging up the phone), and responds with the message NO CARRIER.
4. Follow the same steps if you want to test the Answer frequency, but substitute the Answer command (A) for the Dial command (D). If you've already set the modem for Normal Mode, as in Step 2 above, you don't need to type &M0 again:

```
AT &M0 S16 = 5A <cr>
```

5. Reset your terminal or software to 9600 bps. Reset the modem to its error control and Data Mode defaults with this command:

```
AT &M4 S16 = 0 <cr>
```

You may want to take the time at this point to read the following information on other test options, or skip to Chapter 3 for basic operational guidelines.

### Additional Test Procedures

S-register 16 has five settings, explained in what follows.

- |   |                                   |
|---|-----------------------------------|
| 0 | Data Mode (no testing)            |
| 1 | Analog Loopback                   |
| 2 | Dial Test                         |
| 4 | Test Pattern                      |
| 5 | Analog Loopback with Test Pattern |

1. To perform analog loopback testing of the Originate or Answer frequency without the test pattern, set the terminal or software to 2400 bps and issue either of the following commands:

```
AT &M0 S16 = 1D <cr>
```

```
AT &M0 S16 = 1A <cr>
```

The modem enters Analog Loopback Mode, goes off hook and displays the message CONNECT 2400.

Type any message you wish at the keyboard. It is looped through the modem and returned to the screen.

End the test by not typing anything for at least one second and then typing three pluses. This is an escape code

that forces the modem back to Command Mode (don't type the AT prefix or enter a Carriage Return):

+++

The modem returns the OK message.

To have the modem exit Analog Loopback Mode and hang up the phone, first reset your transmission rate to 9600 bps. Then reset the modem to its error control and Data Mode defaults with this command:

**AT &M4 S16=0 <cr>**

2. The Dial Test is used to test the frequencies of Touch-Tone values. If S16 is set to 2 and a single Touch-Tone is dialed (e.g., ATDT7 <cr>), the modem continues to transmit that tone until another Carriage Return is entered. This test is used in factory testing.
3. The Test Pattern alone (ATS16=4 <cr>) is used for testing equipment and the phone line. If S16 is set to 4 and a Dial command issued, the modem transmits the test pattern upon connection to the remote system. If set for Auto Answer (DIP switch 5 UP), the modem transmits the test pattern when it answers a call.
4. The preceding instructions test the modem at 2400 bps. To test the modem at 1200 or 300 bps, set your terminal or software to the lower speed and follow the same procedures.
5. It might happen that you have issued either S16=1 or 5 and the modem is in Analog Loopback Mode, but you haven't yet sent a Dial or Answer command to initiate testing. If the modem is also set for Auto Answer and a call comes in, the Courier HST resets S16 to zero and answers the call.

**NOTE:** After any testing, be sure to reset S-register 16 for normal Data Mode operations, with or without the default error control setting (&M4):

**ATS16=0 <cr>**

Here are some brief guidelines for immediate operation of the modem.

#### DATA FORMAT

Ten-bit data units: check the table on page 6-1 or page F-1.

#### ERROR CONTROL

Both modems must be set to error control mode for error detection and retransmission to occur. *Always use error control for 9600-bps communications.*

We use the term ARQ (automatic repeat request) for error control. The three ARQ settings are as follows:

**&M0**

Normal Mode. No error control.

**&M4**

Normal/ARQ Mode—Default. The Courier attempts an ARQ connection; if the signal isn't recognized, the modem continues in Normal Mode (&M0).

**&M5**

ARQ Mode. The Courier attempts an ARQ connection; if the signal isn't recognized, the modem hangs up.

#### DIALING

Use these settings/commands to call the following types of modems at the indicated speeds.

*HST-Compatible,  
9600 bps*

Terminal/software: 19.2k (preferable) or 9600 bps

Type:

**AT &H3 D phone number <cr>**

The command includes the setting for hardware/software flow control (&H3). See the flow control guidelines that follow. If the modem isn't set for error control, include &M4 or &M5 in the command line.

*MNP-  
Compatible,  
2400 or  
1200 bps*

Terminal/software: 19.2k, 9600, 2400 or 1200 bps

Type:

**AT &H3 D phone number <cr>**

The command includes the setting for hardware/software flow control (&H3). See the flow control guidelines that follow.

*Non-MNP  
Compatible,  
2400, 1200 or  
300 bps*

See the flow control guidelines that follow.

Terminal/software: 2400, 1200 or 300 bps

Type:

**AT &M0 D phone number <cr>**

**NOTE:** &M0 suppresses the MNP signals that may be misinterpreted by the remote system and prevent a successful connection.

### FLOW CONTROL

Hardware and/or software flow control can be used for transmitted and received data. We recommend hardware Transmit data flow control (&H1) since this setting doesn't affect the data stream. This is especially important if you're transmitting binary data.

Use flow control in any of the following situations.

- You're using error control (9600/2400/1200 bps). Flow control prevents buffer overflow in the event that line disturbances cause frequent retransmissions.
- The rate at the local terminal interface is higher than the link rate.
- The volume of data transfer is high.

Flow control commands are covered in Chapter 4.

### MAXIMUM THROUGHPUT

Use these settings for both Originate and Answer Modes.

Terminal/software: 19.2k bps  
Modem: Fixed terminal interface rate (&B1)  
Variable link rate (&N0)  
Transmit Data flow control (&H1  
preferred, &H2 or &H3)

### HIGH-SPEED CHANNEL TURNAROUND

As described in Chapter 1, HST modems use asymmetric modulation. The modems allocate the high-speed channel on demand so that the modem with the greatest amount of data in its buffer transmits at 9600 bps. Turnaround of the channel is automatic and requires no user intervention.

### LINK NEGOTIATION

When a Courier HST calls an HST-compatible modem and both are operating at 9600 bps, the modems negotiate the link connection ("shake hands") at 2400 bps and automatically resume operation at 9600 bps. The lower handshaking rate maintains compatibility with the existing telephone network as well as existing hardware and software.

It's possible for two HST-compatible modems to connect directly at 9600, without 2400-bps handshaking, but *both modems* must be set as follows:

DATA RATE  
DEFAULTS

Terminal/software: 9600 or 19.2k bps  
 Modem: Fixed link rate of 9600 bps (&N6)  
 Error control, either &M4 or &M5

Terminal interface: &B0, detect rate from the AT command, then follow connection rate.

Link interface: &N0, negotiate the highest possible rate with the remote modem in both Originate and Answer Modes.

The terminal interface and link rates may be set to fixed rates using &B1 and &N1-6, respectively.

NONVOLATILE  
MEMORY  
(NRAM)

The modem is factory set (DIP switch 10 OFF) to load the settings stored in NRAM on power up. Write your own configuration defaults to NRAM with the &W command. To review the NRAM settings, refer to Appendix B-3 or type:

ATI5 <cr>

PHONE  
NUMBER  
STORAGE

Use &Zn = s to store four frequently called phone numbers in NRAM (nonvolatile memory); n = positions 0 through 3, s = number-string. The string may contain a maximum of 36 characters and any Dial command options.

Example: AT&Z = 9,,1 312 5551234 <cr>  
 (Store at position 0)

Example: AT&Z1 = 5551234 <cr>  
 (Store at position 1)

DIALING  
STORED  
NUMBERS

To dial, issue the DSn command, where n indicates the position of the number in NRAM.

Example: ATDS1 <cr> (Dial number at position 1)

The first command in the following sequence stores the phone number and access code for a long distance service. The second command dials the stored number/access code and continues dialing the long distance phone number.

AT&Z2 = 5551234,,9876,, <cr>  
 ATDS2 D1 312 5556789 <cr>

### BUSY ANSWER

Use A> instead of A/ and the modem redials up to 10 tries instead of once. Neither A> nor A/ takes the AT prefix or a Carriage Return.

Add the Repeat Mode command (>) to the Dial command string and the modem automatically redials up to 10 tries:

```
AT>D5551234 <cr>  
ATD5551234> <cr>
```

You may include the Repeat command when you store a phone number-string in NRAM:

```
AT&Z2 = 5551234> <cr>
```

### INACTIVITY TIMER

Set the inactivity timer (S-Register 19) if you suspect that a connection may be inadvertently left open without data transfer.

Use the commands explained in this chapter to select the modem's operating characteristics at the terminal and link interfaces. The commands apply to error and flow control, and to the speed-select options at both interfaces. ► For background information on these features, see Appendix A.

**NOTE:** When you change a default setting during a session, the modem retains that setting until you do one of the following:

- Select a new setting.
- Issue the Z command to reload the NRAM defaults or the &F command to load the factory settings.
- Turn the modem off.

## TERMINOLOGY

For simplicity, references to a *terminal* in this chapter mean both conventional terminals and microcomputers. *ARQ* (automatic repeat request, i.e. retransmission) is the term used by USRobotics in error control commands and response codes.

In summaries, the terminal is referred to as *DTE*, for Data Terminal Equipment, while the modem is referred to as *DCE*, for Data Communications Equipment. DTE/DCE indicates the terminal/modem interface. DCE/DCE indicates the link (modem-to-modem) interface. (For more information see the Flow Control section in Appendix A.)

## ERROR CONTROL

While error control is optional, it should always be selected for 9600 bps sessions. The USR-HST protocol is used at 9600 bps. The MNP protocol is used at 2400 and 1200 bps. Both protocols use cyclic redundancy checking for error detection, and an automatic repeat request (ARQ) for retransmission of errored data frames.

## ARQ Retry Timer

It may happen that a retransmission request for the same frame occurs repeatedly. Ordinarily this is due to a serious disturbance in the phone connection. The retry maximum is 12, after which the modems automatically hang up instead of running up wasteful phone charges. If the Courier hangs up and you don't know why, query register S20 with this command:

```
ATS20? <cr>
```

If a code of 6 is returned, the modems reached the retry timeout and hung up. Place the call again; you'll more than likely get a better connection.

**Error Control Modes (&Mn)**

Under error control, the calling modem includes an error control request in its link negotiation signals. The answering modem may or may not recognize the request. The following options allow you to select a setting best suited to your default configuration as well as to individual calls.

**&M0** Normal Courier Mode, no error control. Use this setting if you're calling a non-MNP modem (2400/1200/300 bps), as the error control request may be misinterpreted by the remote system and prevent a connection. Don't use this setting for 9600-bps calls.

**&M1-3** These options are reserved for future use.

**&M4** Normal/ARQ Mode. If the remote modem doesn't recognize the Courier's error-control request, the Courier automatically operates in Normal Mode (&M0). This setting is the default. Use this adaptive mode if error control isn't crucial.

**&M5** ARQ Mode. If the remote modem doesn't recognize the error-control request, the Courier HST hangs up. Use this setting if error control is an absolute requirement.

**With Auto Answer**

To use error control for incoming calls, set the modem for Auto Answer and for either &M4 or &M5. When calls come in, the Courier HST goes off hook and responds to an error-control request if one is sent. If the Courier doesn't receive a request and is set to Normal/ARQ Mode (&M4), it answers the call in Normal Mode. If it doesn't receive a request and is set to ARQ Mode (&M5), it hangs up.

**FLOW CONTROL COMMANDS**

Flow control is used to control the flow of data input to and output from the modem, to prevent data loss. For more information, refer to Appendix A.

The Transmit Data flow control command, &Hn, controls the flow of data from the terminal to the modem. Two commands, &In and &Rn, control the flow of Received Data.

The factory-set default of the Courier HST is flow control disabled. As mentioned in Chapter 3, flow control should be enabled in the following situations.

- You're using error control (9600/2400/1200 bps). If you're transmitting and problems on the line cause a number of retransmissions, input from the

terminal will back up and perhaps overflow the modem's buffer.

- The rate at the terminal interface differs from the link rate, e.g., the terminal's sending at 19.2k bps and the link rate is 9600 bps. This setup offers the greatest throughput, but the modem requires the ability to signal the terminal when the modem's buffer is reaching capacity.
- The volume of data transfer is high.

### Transmit Data Flow Control (&Hn)

The modem monitors its buffer as data comes from the terminal. If the buffer approaches 90% capacity, the modem signals the terminal to stop sending. When the modem has sent enough data over the link to half empty the buffer, it signals the terminal to resume transmitting.

Two types of signals are used:

- Hardware: the modem raises or lowers the Clear To Send (CTS) signal via Pin 5 on the RS-232C interface.
- Software: the modem sends the conventional ASCII Transmit on/off (XON/XOFF) characters, as follows:

XON    <Ctrl>-Q    (ASCII 17 Decimal, 11 Hex)  
XOFF   <Ctrl>-S    (ASCII 19 Decimal, 13 Hex)

The ASCII characters may be user-defined; see S-registers S22 and S23 in Appendix B-5 and the ASCII chart in Appendix B-6 or on the Quick-Reference card.

**NOTE:** If possible, use hardware control as it is more efficient and doesn't affect the data stream.

- &H0**    Flow control of transmitted data is disabled. This setting is the default.
- &H1**    Use hardware flow control. If your terminal supports Clear To Send (CTS, RS-232C Pin 5), the Courier lowers CTS when the buffer nears 90% capacity, and raises CTS again when the buffer is about half full.
- &H2**    Use software flow control. The Courier sends the terminal the XON/XOFF characters to control the input of data to the buffer.
- &H3**    Use both hardware and software flow control. If you are unsure about what your equipment supports, select this option.

### Received Data Flow Control

Modems operating in error-control mode automatically control the flow of data on the data link. The commands described here control Received Data passed by the modem to the terminal. If the data rate at the terminal interface is 9600 or 19.2k bps, there may be a need at times to signal the modem to temporarily stop passing data. You may want to try using one of the two following commands to set the modem to respond to flow control signals. The modem stops the output of data to the screen and retains any data in the buffer until signaled to resume.

### *Software Control (&In)*

If your terminal supports the <Ctrl>-S and <Ctrl>-Q commands, you can use the &I command to set the modem to respond to XON/XOFF signals.

**&I0**

Disable XON/XOFF flow control of received data. This option makes all characters, including control characters, transparent to both modems. This setting is the default.

**&I1**

Typing <Ctrl>-S/<Ctrl>-Q causes XON/XOFF signals to be sent to both the local modem and the remote system. If any data is in transit before the remote system stops transmitting, the Courier saves the data in its buffer.

This setting is especially useful if you want to stop the scrolling of incoming data so you can review it. When the modem receives the <Ctrl>-S, the data immediately stops scrolling.

**&I2**

The modem acts on XON/XOFF signals but doesn't pass them on to the remote system. This is a safeguard in case the remote system uses <any key> instead of <Ctrl>-Q for XON signaling. If a remote terminal has received an XOFF from its own modem, it will interpret your XOFF as <any key>, i.e., XON, and resume transmitting data.

**&I3**

Hewlett Packard protocol—Host Mode. This setting only applies to modems attached to an HP mainframe. ➤ See Appendix E-5.

**&I4**

Hewlett Packard protocol—Terminal Mode. This setting only applies to modems attached to terminals in an HP system. ➤ See Appendix E-5.

## Hardware Control (&Rn)

If the terminal supports Request To Send (RTS) on the RS-232C interface (Pin 4) and RTS is not always high, the terminal lowers RTS to signal the modem to stop passing it received data, and raises RTS when it is ready to receive.

**&R0** Reserved.

**&R1** Ignore RTS. This is the default. This setting is required if your terminal does not support RTS.

**&R2** The modem only sends data to the terminal when RTS is high.

## DATA RATE COMMANDS

Two commands control the data rate at the terminal and link interfaces, &Bn and &Nn, respectively. At the default settings (&B0, &N0) the modem determines its rate in the following ways:

- Initially the modem detects its rate from the rate at which the terminal sends it the AT command. That rate is determined by the terminal or software setting.
- When originating or answering a call, the Courier and the remote modem negotiate the highest possible link rate. For example, if the terminal sends the AT command at 9600 bps and the Courier calls a modem operating at 1200 bps, the Courier automatically falls back to 1200 bps. The Courier notifies the terminal of the adjustment by sending the result code CONNECT 1200.

The Courier readjusts to 9600 bps at the next AT command or, if auto answering a call, readjusts to the rate of the incoming call. ➤ See Appendix E-2 for more details.

**NOTE:** The adjustments occur up to the rate ceiling set at the terminal. If for some reason the terminal rate is set to 2400 bps and the Courier calls an HST-compatible operating at 9600 bps, the remote modem drops back to establish a 2400-bps connection.

## Optional Fixed Rates

Optional speed settings allow you to fix the rate at either the terminal or link interface, or both. These settings apply to both normal and error-control operations, but *be sure to enable Transmit Data (&H) flow control.*

**Terminal Rate Select (&B*n*)** Use this command to select varying or fixed rates at the terminal interface. Fixing a maximum rate at the terminal interface offers greater efficiency, regardless of the modem at the remote end of a connection.

**&B0** Variable rate: the terminal interface rate follows the connection rate. Use this setting if your software switches its rate when it receives the CONNECT result codes, e.g., CONNECT 2400, CONNECT 1200. The modem readjusts at the next AT command or connection.

**&B1** Fixed rate: allowable terminal/software settings are 19200/9600/2400/1200/300 bps. Setting the terminal to 19.2k bps enables the greatest throughput. ➤ See guideline number 2 below.

**Link Rate Select (&N*n*)** If the &B and &N settings differ, be sure to use flow control to prevent the possibility of data loss.

**&N0** Normal operations: the link rate varies according to the connection sequence.

**&N1–6** Fixed link rate: the modem only connects if the remote modem is also operating at the same rate. Allowable rates are as follows:

&N1	300 bps	&N4	Reserved
&N2	1200 bps	&N5	Reserved
&N3	2400 bps	&N6	9600 bps

**Rate-Select Guidelines**

1. Some software doesn't support a fixed terminal rate, but always switches bit rates to the link rate established by the modems during their connect sequence. In this case, leave the Courier set to &B0.
2. For maximum throughput, use the settings recommended in Chapter 3 for both Originate and Answer Modes:

Terminal: 19.2k bps  
Modem: Fixed terminal interface rate (&B1)  
Variable link rate (&N0)  
Transmit Data flow control (&H1, 2, or 3)

3. You can filter out calls at other than a specific speed, for security or other reasons, by fixing the link rate.
4. If the Courier HST is connected to a mainframe, the mainframe may require that the terminal and link rates be fixed with the &B and &N commands.

DSR OVERRIDE  
(*&Sn*)

The Data Set Ready (DSR) function (Pin 6 on the RS-232C interface) is required on some systems to enable the modem to signal the terminal when the modem is ready to answer a call. Typically, DSR signaling is overridden.

*&S0* DSR is always ON (overridden). This setting is the default.

*&S1* The modem controls DSR.



The commands explained in this chapter are of two types. The first group concerns default configurations, for example, writing your own power-on defaults to nonvolatile random access memory (NRAM). The remaining commands are used to select the modem's local operating characteristics, for a current session or to include in your default configuration. They include result code, echoing, and other options.

**NOTE:** When you change a default setting during a session, the modem retains that setting until you do one of the following:

- Select a new setting.
- Issue the Z command to reload the NRAM defaults or the &F command to load the factory settings.
- Turn the modem off.

## SETTING/USING DEFAULTS

The Courier HST is shipped from the factory with its software defaults stored in read only memory (ROM) and also in programmable nonvolatile random access memory (NRAM). The inclusion of NRAM allows you to program your own configuration and save the settings as your power-on defaults.

### Writing Defaults to NRAM (&W)

If you store your own default software settings in NRAM, the Courier loads those settings when it is powered on if DIP switch 10 is UP (factory setting).

A list of the settings stored in NRAM is in Appendix B-4. You can also display the settings at any time by selecting option 5 of the I (inquiry) command:

```
ATI5 <cr>
```

If you've sent the modem commands to change settings throughout your session and want to save your current configuration, issue the &W command:

```
AT&W <cr>
```

You can also specify your configuration in a single command string that includes the &W command, as in this example:

```
AT X4 &B1 &M5 &H1 &I1 M3 &W <cr>
```

Modify one or several settings at any time, for example:

```
AT X7 &W <cr>
```

Loading the  
Factory Defaults  
(&F)

Factory defaults are permanently stored in read only memory (ROM). They are listed in the table of NRAM settings in Appendix B-4. You can set the modem to its factory defaults during any session by typing:

```
AT&F <cr>
```

If DIP switch 10 is DOWN, the factory settings are loaded at power on instead of the NRAM defaults.

Resetting to  
NRAM Defaults  
(Z)

To reset the modem to its NRAM defaults, type:

```
ATZ <cr>
```

**NOTE:** On reset, the modem also checks the status of DIP switches 2–5 and 9: if you change the setting of any of these switches when the modem is on, use the Z command to initiate the new setting(s).

Storing  
Telephone  
Numbers  
(&Zn = s)

The modem stores up to four frequently called phone numbers. Write the numbers to NRAM with the &Zn = s command, where n is position 0 through 3, and s is the number-string.

The number-string may be up to 36 characters long, including any Dial command options. The following example includes the tone-dial (T) and comma pause options of the Dial command. The number is stored at position 0, assumed because there is no n parameter.

```
AT&Z = T9,,5551234 <cr>
```

The next example stores the phone number and user's access code for a long distance phone service.

```
AT&Z1 = 5551234,,9876,, <cr>
```

Dial the stored number using the DSn command, for example, DS2 <cr>. Additional examples are in Chapter 6.

**NOTE:** Don't include modem settings in the &Z string. If the call requires a special setting, insert the appropriate command when you dial the stored number. In the following

example, &M0 (no error control) is substituted for the user's error control default setting:

**AT&M0DS2 <cr>**

Then reset the error control mode after the call, for example:

**AT&M4 <cr>**

**RESULT CODES**

Four commands control the result codes the modem returns to the screen:

- Vn*      Numeric/verbal response mode
- Xn*      Result code subset
- Qn*      Display/suppress all result codes
- &An*    Display/suppress /ARQ result codes

**Response Modes (Vn)**

Result codes are sent to the screen in either words (Verbal Mode) or numbers (Numeric Mode). The Courier is factory set to verbal messages when it is powered on (DIP switch 2 is UP). Use the V command to select verbal/numeric result codes independently of the power-on default.

**V0**      Numeric Mode. Numeric result codes are followed by a Carriage Return but no Line Feed, as in the following example, where a 3 is returned (for NO CARRIER).

**ATD1234567 <cr>**  
 becomes  
**3TD1234567 <cr>**

**V1**      Verbal Mode. Verbal responses are preceded and followed by a Carriage Return and a Line Feed, as in the following example:

**ATD1234567 <cr>**  
**NO CARRIER**

**Result Code Sets**

A table of result code options is on the next page. The format of the command to select a result code set is **ATXn**, where *n* is a value from 0 through 7:

**ATX0**    Basic subset, returns the first five codes (0-4) in the following table.

**ATX1**    Extended subset, codes 0-5, 10 and 13. Default. This set adds rate-specific CONNECT messages to the Basic set.

**ATX2-7**    These options offer advanced call-progress codes and functions.

RESULT CODES OPTIONS TABLE								
Commands								
X0 X1 X2 X3 X4 X5 X6 X7								
Result Codes								
0/OK	X	X	X	X	X	X	X	X
1/CONNECT	X	X	X	X	X	X	X	X
2/RING	X	X	X	X	X	X	X	X
3/NO CARRIER	X	X	X	X	X	X	X	X
4/ERROR	X	X	X	X	X	X	X	X
5/CONNECT 1200		X	X	X	X	X	X	X
6/NO DIAL TONE			X		X		X	X
7/BUSY				X	X	X	X	X
8/NO ANSWER				X	X	X	X	X
9/Reserved								
10/CONNECT 2400		X	X	X	X	X	X	X
11/RINGING						X	X	X
12/VOICE						X	X	
13/CONNECT 9600		X	X	X	X	X	X	X
Functions								
Adaptive Dialing			X	X	X	X	X	X
Wait for 2nd Dial Tone (W)					X	X	X	X
Wait for Answer (@)					X	X	X	X
Fast Dial			X		X		X	X

Options  
Summary

1. An additional group of CONNECT messages (15–17) indicates an error-control connection with an HST- or MNP-compatible modem. ➤ See the “/ARQ Result Codes (&An)” later in this section.
2. Adaptive dialing causes the modem to automatically use Touch-Tone dialing and, if that doesn’t work on the line, revert to pulse dialing.
3. W and @ are Dial options described in Chapter 6.
4. Fast dial causes the modem to dial as soon as a dial tone is detected, rather than wait the normal two seconds. If there is no dial tone, the modem times out after 5 seconds and sends the NO DIAL TONE (6) result.
5. After sending the BUSY (7) result code, the modem hangs up.

6. The NO ANSWER (8) result code is returned, instead of the standard NO CARRIER, when the @ option is used and there is no answer at the remote end.
7. After sending the VOICE (12) result code, indicating a voice answer, the modem hangs up.
8. X6 implements all result codes and functions. X7 includes all of X6 except the VOICE (12) result code.

Quiet Mode (Qn)

Enable/suppress the display of result codes. The Courier is shipped with DIP switch 3 DOWN and defaults to display ON when the modem is powered on. The commands here control the display independently of the power-on default.

*Q0* Result codes are displayed.

*Q1* Result codes are suppressed (made "quiet"). This is useful when the messages might interfere with the data stream.

/ARQ Result Codes (&An)

If these codes are enabled, one of the following results is sent to the screen when a successful HST or MNP connection is established. (A setting of X1 or higher is assumed.)

- (15) CONNECT 1200/ARQ
- (16) CONNECT 2400/ARQ
- (17) CONNECT 9600/ARQ

*&A0* /ARQ codes are disabled. Some software does not allow the /ARQ result codes. In this case, use this setting. Suppression of the /ARQ codes doesn't affect the error control protocol; the modem returns the standard CONNECT messages.

*&A1* /ARQ codes are displayed. This is the default.

LOCAL ECHO

Two commands control what the modem displays on the screen. The *En* command applies to when the modem is in Command Mode. The *Fn* command applies to when the modem is online to another system.

Command Mode Local Echo (En)

The *En* command enables/disables the display of your typed commands. If double characters appear on the screen, both the modem's local echo and the software's local echo are on. The Courier is shipped with DIP switch 4 UP, for local echo ON when the modem is powered on. The commands here control the echo independently of the power-on default.

*E0* Command Mode echo OFF. The modem does not display keyboard commands.

*E1* Command Mode echo ON.

Online Local  
Echo (Fn)

This command causes the modem to display a copy of the data it is transmitting to another system. Many systems, however, return a copy of received data, which is called a remote echo. If the modem's online echo is ON and there is remote echoing, double characters appear on the screen.

In some microcomputer documentation the online echo setting is called the "Duplex" setting, although the term is not technically accurate.

F0

Online echo ON. Sometimes called Half Duplex. As the modem transmits data to a remote system, it also sends a copy of the data to the screen.

F1

Online echo OFF. Sometimes called Full Duplex. This is the default.

THE AUDIO  
MONITOR

The modem's speaker enables you to monitor the dial-connect process. There are several ways to make use of this feature. After the Courier HST dials a number, it waits 30 seconds for a high-pitched answer tone from the other modem, immediately followed by data signals, called a *carrier*. These signals must occur before a data link is established.

If someone answers the phone, or if the line is busy, the modem sends the message NO CARRIER to your screen after 30 seconds. If you listen to the speaker, you can respond immediately instead of waiting for the modem to time out.

For example, if you hear someone answering the call, you might pick up the phone and talk to the person or cancel the call by pressing any key on the keyboard. In the same way, you can cancel a call when you hear a busy signal.

You can also hear if dialing is proceeding too fast for the system. Terminate the call (press any key) and reenter the Dial command with a comma or two to allow more time. This applies to accessing an outside line (dialing 9, for example) as well as to checking out whether a public service has enough time to respond to your account number or other code.

Speaker Control  
(Mn)

You can disable the speaker entirely or set the speaker to monitor different segments of the dial-connect sequence.

*M0* The command `ATM0` turns the speaker OFF entirely so that you don't hear the modem go off hook, dial, etc.

*M1* The speaker is ON until Carrier Detect. This is the default setting and lets you monitor call progress until the Courier detects the remote modem's carrier signals, or until the 30-second timeout and result code display. At Carrier Detect, the modem disconnects the speaker and data transmission sounds are suppressed.

*M2* The speaker is ON continuously, including during data transmission.

*M3* The speaker doesn't go ON until after the last digit is dialed, then goes OFF at Carrier Detect.

#### MODEM CLOCK USAGE (*Kn*)

The modem clock is used as a call-duration timer or as a real-time clock. Used in conjunction with the *In* (Inquiry) command, the modem returns the duration of the last call in hours, minutes, and seconds or the actual time.

*K0* Call-Duration Mode: the modem times each call from CONNECT to NO CARRIER, and stores the information until the next connection or the modem is reset. At `ATI3 <cr>`, the modem displays the call's duration. If you wish, you can maintain a call log by printing this information after each call. This setting is the default.

*K1* Real-Time Mode: the clock operates as a real-time clock regardless of the presence of a carrier. Set the clock (military time) by specifying the hour, minutes, and seconds as in the following example, which sets the clock at the real time of 1:30 p.m.

```
AT13 = 13:30:00 K1 <cr>
```

At `ATI3`, the modem displays the real time. You'll need to set the clock each time you power on the modem, but the clock is not affected by the reset command, `ATZ`.

#### TRANSMITTER ENABLE DISABLE (*Cn*)

If an additional terminal and modem share the phone line for monitoring purposes, the second modem is placed in Receive Only state by disabling its transmitter.

*C0* Transmitter disabled. Modem is set to Receive Only.

*C1* Transmitter enabled. This is the default.

### BREAK HANDLING (&Yn)

The Courier HST allows you to send a break to abort data transfer without disconnecting from the data link. The following options are available.

- &Y0* Destructive, no Break transmitted: the modem clears the data from its transmit buffer (all data is lost) but does not pass on the Break to the remote modem.
- &Y1* Destructive, expedited: the modem clears the buffer and immediately sends a Break to the remote modem. This is the default setting.
- &Y2* Nondestructive, expedited: the modem retains buffer data, but immediately sends a Break to the remote modem.
- &Y3* Nondestructive, unexpedited (send Break in sequence): the modem transmits any buffer data received before the Break, sends the Break, and then sends any subsequent input from the computer or terminal.

### THE S-REGISTERS

The S-Registers are used to set various timing parameters and other operations, including redefinition of selected ASCII characters. The defaults typify the requirements of most users.

► A detailed summary of the S-Register functions is in Appendix B-5. Less detailed summaries are on the bottom label of the modem case and in the Quick-Reference card.

BASIC  
REQUIREMENTS

To successfully establish a communications link, the called or calling modem must be compatible with the following standards at the specified bit rates.

Bits per Second	Standard
9600	USR-HST or compatible
2400	CCITT V.22 <i>bis</i>
1200	Bell 212A
300	Bell 103

To successfully exchange data, both modems must use the same 10-bit data format. The formats allowed are as follows:

Start Bits	Data Bits	Parity	Stop Bits
1	7	Even, Odd, Mark, Space	1
1	7	None, Even, Odd, Mark, Space	2
1	8	None	1,2

Transmission  
Rate

In general, you should know the transmission rate of the other modem before calling. However, if the link rate is set to the default, &N0, and the Courier HST tries to connect with a modem operating at a lower rate, the Courier falls back to the rate of the remote modem. This applies to both Originate and Answer Modes. ➤ See the discussion under "Data Rate Commands," in Chapter 4.

Error Control

Always set the Courier HST for error control, &M4 (the default) or &M5, for 9600 bps connections.

It helps to know if the remote modem is MNP-compatible at 2400/1200 bps. Some public network services, for example, are not. When the Courier HST is set to &M4 it includes an error-control link request in its handshake signals. If the remote modem isn't under error control, the Courier operates in Normal Mode (no error control). However, if the remote modem doesn't support the MNP protocol at 2400

or 1200 bps, the MNP link-request signals may be misinterpreted and block a successful connection. If you know the remote modem doesn't support MNP, we recommend setting the Courier HST to &M0 before dialing.

Automatic Retrain

An HST or V.22bis modem sends a retrain signal if it senses that a problem in the phone line connection may be causing data unreliability. The modems stop the transfer of data for about a second while they resynchronize, and then resume Data Mode operation.

Retraining only occurs during 9600 and 2400 bps communications. ➤ For a description of the signaling sequence, see Appendix E-3.

PLACING CALLS

The commands discussed in this section are used in the following operations:

- Dialing D (0-9 # \* , ; ! P T W (@ R), DS*n*
- Redialing A/, A>, >
- Canceling dialing <any key>

Dial (D)

When the Dial command is issued the modem goes off hook—the equivalent of your picking up the phone—then enters Originate Mode and dials the number sequence that follows. The modem also executes any other commands or options included in the command line.

The command string may include up to 40 characters, plus the AT prefix and Carriage Return/Enter key. The modem doesn't count spaces. It counts punctuation characters such as parentheses and hyphens, but ignores them.

The following command instructs the modem to stop the display of commands (E0, turn off the local echo), to dial (D) using Touch-Tone dialing (T), and to turn off the speaker (M0). The spaces shown are ignored by the modem and are only included here for readability.

```
AT E0 DT 1234567 M0 <cr>
```

Dialing Type (P, T)

If set to X0 or X1, the modem defaults to pulse (rotary) dialing. To have the modem use tone dialing, use the T command, which also allows you to use the asterisk (\*) and

pound sign (#). The command may be included in the Dial string, as in the above example, or issued separately:

```
ATT <cr>
```

The following command resets the modem to pulse dialing:

```
ATP <cr>
```

You can switch from one dial type to another within a dialing sequence. For example, you might have a phone line that only accepts pulse dialing (slower than Touch-Tone dialing) but subscribe to a long-distance service that accepts tone dialing, such as MCI. You can switch to tone dialing once you've hooked into the long-distance service. In the following example, a switch is made to tone dialing before entering a service account number and the long-distance destination. (The commas are discussed shortly.)

```
ATDP 9,,7654321,,T 55555,,1 312 1234567 <cr>
```

**NOTE:** The modem remains set for Touch-Tone dialing until it is reset or the ATP (pulse) command is reissued.

### *Adaptive Dialing (X2–X7)*

When any of the X2 through X7 options is in effect and you don't issue a dialing type in the Dial string, the Courier uses tone dialing, which is faster than the default pulse type. However, if the phone company central office doesn't have Touch-Tone detection equipment, the modem can not "break dial" and continues to detect the dial tone. If this occurs, the modem automatically reverts to pulse dialing.

### *Pause (,)*

A comma causes a two-second delay in the dial sequence. The following example contains four-second delays at several points:

```
ATDP 9,,7654321,,T 55555,,1 312 1234567 <cr>
```

The first four-second pause is to access an outside line after dialing 9, the second to make sure the remote computer is ready for the user's account number, and the third, to delay before dialing the long-distance number.

Such pauses, however, may not be necessary. Experiment and use delays only as required.

*Dial and Return  
to Command  
Mode (;)*

Use this option to have the modem Auto Dial a telephone rather than a modem. The Courier dials, remains off hook and returns the OK message, indicating it is in Command Mode.

For example, if your phone is plugged into the modem you can have the modem place a voice call. Issue the Dial command with a semicolon:

```
ATDT5551234; <cr>
```

When the modem returns the OK result, pick up your phone receiver so you can talk to the other party and tell the modem to hang up:

```
ATH <cr>
```

Similarly, you can call a recorded weather or other service. Have the modem Dial, listen to the recording over the modem's speaker and, when you're finished, tell the modem to hang up.

Another example is an information or other service that requires a Touch-Tone entry of an ID as part of the log-on procedures. The following sequence is an example.

```
ATDT1234567; <cr> (dial the service's telephone  
number and return to Com-  
mand Mode)  
OK  
ATDT65432; <cr> (dial ID and return to Com-  
mand Mode)  
OK  
. . .  
ATH <cr> (session is finished;  
hang up)  
OK
```

*Dialing  
Letters (")*

Quotation marks are used to have the modem dial abbreviations and acronyms used as phone “numbers,” such as DIAL USR (the USRobotics Sales Department’s 800 number). The option is called Quote Mode. Quotation marks are inserted at the beginning of the alphabetic string:

```
ATDT"BBS-NEWS <cr>
```

If you’re including another command after the dial string, use closing quotation marks before the additional command.

*Transferring  
Calls (!)*

This command applies to modems in installations where other modems share the phone line. The modem flashes the switch-hook, i.e., goes off hook 0.5 seconds, on hook for 0.5 seconds, and off hook again to dial the specified extension. The following example includes instructions to return to Command Mode (;) and to hang up (H).

```
ATDT !1234;H <cr>
```

*Wait for a  
Second Dial  
Tone (W)*

This command is useful in situations where you must wait for a second dial tone before entering a password, for example, when using MCI, Sprint, or other long-distance service. The following command tells the modem to dial the service number, wait for the second dial tone, dial the ID, pause two seconds, then place the long-distance call.

```
ATDT 5551234 W 12345, 3121234567 <cr>
```

**NOTE:** This command executes only if result code option X3 or greater has been issued. If the modem is set to X2 or lower, the modem interprets the W as a comma (two-second pause).

*Wait for an Answer (@)*

Some online services answer the phone and return a tape-recorded request for information before processing transactions. In such instances, the @ command can be used in the Dial string to tell the modem to detect at least one ring, wait for five seconds of silence at the other end of the call, and then continue to execute the Dial string.

To use the @ command, set the modem to X3, X4 or X7. If the modem is set to X2 or lower, the modem returns an ERROR message when encountering the @ character in a command string. If set to X5 or X6, the modem hangs up when it detects a voice answer and sends the VOICE result code.

In the next example, the modem is set to the X4 result code option and dials a banking service. Each occurrence of @ in the example indicates a five-second wait for silence after taped requests from the bank for the labeled items. The transaction code might be used, for example, to request an account balance.

```
ATX4 DT1234567 (@ 12345 (@ 6789 (@ 2
                        /      /      /
                        Account #  Transaction Code
                        Password
```

If the necessary conditions don't occur—no rings, or no following five seconds of silence—the modem times out as it normally would (after 30 seconds). It then sends the message NO ANSWER to the screen and aborts the command.

*Reversing Originate/Answer Frequencies (R)*

This command allows calls to an originate-only modem. It reverses the modem's originate/answer frequencies, forcing the Courier to dial out at the answer frequency. The command follows the Dial command, before or after the phone number:

```
AT D1234567R <cr>
AT DR1234567 <cr>
```

**CANCELING DIALING**

To cancel dial-command execution, press <any key>. If you inadvertently hit a key on the keyboard while the modem is dialing, the call is canceled. If this occurs, type the A/ command explained in the next section.

**REDIALING**

The most frequent reason for redialing is receipt of a busy signal. The Courier HST provides three ways to redial, as follows.

**Reexecute the Last Command (A/)**

The A/ command, which doesn't take the AT prefix or a Carriage Return, redials one time:

```
A/
```

When the modem receives a command, it stores the instruction in its command buffer until the next AT command is received. Note that if you've sent the modem an additional command since the Dial command, A/ reexecutes that command instead of redialing.

**Automated Redialing (>, A>)**

These two commands, while they can be used to continuously repeat any command, are designed for automated redialing. The first (>) is included in the Dial command. The second (A>) is used alone to redial the command string in the buffer.

**Continuous Repeat (>)**

If you know the modem you're calling is frequently busy, include the Repeat command in the Dial string, as in either of the following examples:

```
AT > DT 1234567 <cr>
AT DT 1234567 > <cr>
```

The modem enters Repeat Mode, dials the number, waits the default 30 seconds for a carrier, and hangs up. Then, after a two-second pause, it redials.

The cycle continues until the modems connect or the modem reaches a maximum of 10 attempts. The 10-try limit is mandated by the Canadian Department of Communications (DOC) to prevent tying up local telephone company exchanges with unconnected calls.

**Continuous Reexecute (A>)**

This command combines the features of both the A/ and > commands. The modem enters Repeat Mode as described above, and continuously redials the Dial string in the command buffer. Like the A/ command, A> doesn't take the AT prefix or a Carriage Return:

```
A>
```

**Exiting Repeat Mode**

Should you use > or A> with a command other than a Dial string, abort the cycle by pressing <any key>.

To abort automated redialing, be sure to press <any key> when the result code appears, during the pause before the

modem begins dialing again. If you press <any key> while the modem is dialing, that dial attempt is canceled but the cycle continues.

DIALING  
A STORED  
NUMBER (DS*n*)

Chapter 5 includes instructions for storing up to four telephone numbers in nonvolatile random access memory (NVRAM). To have the modem dial a stored number use the DS*n* command, where *n* is the number's position, 0-3, in NVRAM. In the first of the next two examples, the phone number is stored at position 0, assumed by the modem if there is no numeric parameter:

```
ATDS <cr>  
ATDS3 <cr>
```

If you've stored a long distance service number/access code, for example at position 1, use the DS*n* command to dial the number and code, and follow that with a Dial command to dial the call's destination. (The spaces are included for readability.)

```
AT DS1 D 312 5556789 <cr>
```

PULSE DIAL  
MAKE BREAK  
RATIO (&P*n*)

This command sets the ratio of the off-hook/on-hook (make/break) interval when the modem pulse dials. The factory-set default sets the modem for use in North America. The ratio must be changed if the modem is used in the British Commonwealth, with the exception of Canada.

*&P0* North America make/break ratio: 39%/61%. This is the default.

*&P1* British Commonwealth make/break ratio: 33%/67% (excluding Canada).

ESCAPE CODE  
OPERATIONS  
(+++)

Once the modem is online to another system, the only command it recognizes is an escape code of three pluses, which forces the modem back to Command Mode:

- Wait one second after entering the last item of data
- Type: +++
- Wait one second before typing any data

Do not type the AT prefix or a Carriage Return. The guard time of one second before and after the code prevents the modem from misinterpreting the occurrence of +++ in the transmitted data stream.

If necessary, the character used in the escape code can be changed by resetting S-register 2. ➤ See Appendix B-5.

**ARQ Mode Response**

If the modem has been connected under error control it automatically hangs up on detection of the escape code, returns to Command Mode, and sends the NO CARRIER result code.

**Normal Mode Responses**

In Normal Mode, the modem returns to Command Mode when it detects the escape code. However, it keeps the line open or hangs up, depending on the setting of DIP switch 9:

DIP Switch 9	Response to + + +
DOWN	Modem maintains connection OK result code
UP	Modem goes on hook (hangs up) NO CARRIER result code

The factory-set position of DIP switch 9 is DOWN. Retain this setting if you want the modem to execute commands and return online. (See the O command, below.) Keep in mind, however, that this only applies to Normal Mode connections.

If you want an automatic disconnect when you issue + + +, set switch 9 UP. An advantage of this is that you're not likely to inadvertently run up an all-night phone bill.

**WARNING**

For unattended modem operations: in rare instances, the modem may fail to recognize the + + + escape code sequence. If you are running the modem under software control for unattended operations, we suggest you use the surefire method of *dropping the RS-232C DTR signal for at least 50 milliseconds*, to ensure against costly phone charges. Methods of turning the DTR signal off, e.g., closing the communications port, differ from one computer to another.

**RETURNING ONLINE (O)**

If DIP switch 9 is DOWN (on detection of the escape code the modem maintains the connection), you can issue commands and then toggle the modem back online with the O command:

**ATO <cr>**

## HANGING UP (Hn)

If DIP switch 9 is UP for a Normal Mode connection and for all ARQ connections, the modem automatically hangs up when it detects the escape code. If DIP switch 9 is DOWN, first send the escape code to force the modem back to Command Mode. When the modem sends the OK result code, issue the command to hang up:

```
ATH <cr >
```

## AUTOMATIC ANSWERING

The Courier HST is shipped with DIP switch 5 DOWN, Auto Answer suppressed. To set the modem to automatically answer incoming calls, do one of the following:

1. Before powering on the modem, set DIP switch 5 UP. When you turn the modem on, it answers incoming calls on the first ring.
2. If the modem is on, use software control. The following command instructs the modem to answer on the first ring. (You can substitute a higher value. See the S-Register summary in Appendix B-5.)

```
ATS0 = 1 <cr >
```

When the modem senses a call coming in, it sends the result code RING to your screen, goes off hook, and sends the remote modem a high-pitched answer tone. If there is no Carrier Detect within 30 seconds, the modem hangs up and sends the NO CARRIER result code. If the connection is made, the modem sends a CONNECT result code. When the call is disconnected by you or the remote user, the modem hangs up and returns the NO CARRIER code.

## Suppressing Auto Answer

To disable Auto Answer, reverse steps 1 or 2 above. Set DIP switch 5 DOWN before powering on the modem or, if it is powered on, use the command to set the modem to answer on zero rings:

```
ATS0 = 0 <cr >
```

## Points to Remember

1. If the modem is attached to a computer, you can set the modem to receive calls when you're not there. Put the modem in Terminal Mode and set it for Auto Answer. Also set your software's file-save function to save incoming messages and/or files.
2. If you've attached your phone so it can be used for conventional calls, disable Auto Answer when you're not

expecting incoming calls. Otherwise, your modem may answer the phone before you do, greeting your caller with a high-pitched, irritating answer tone.

U.S. CCITT  
ANSWER TONE  
(Bn)

In the United States and Canada, modems use a 2225 Hz answer tone. Outside North America, most modems adhere to the CCITT V.25 standard and send out a 2100 Hz tone followed by a 2250 Hz tone. If you're expecting an overseas call, set the Courier to use the CCITT answer tone. The setting won't affect the modem's ability to connect with a domestic modem although it will take slightly longer to connect with a calling modem.

- B0* CCITT answer sequence, used to answer calls originating outside North America.
- B1* U.S. answer sequence. This is the default.



## USER INQUIRIES

*(ln)*

The Inquiry command has seven options. The most commonly used options display the following information:

- ATi3 Call duration
- ATi4 Current settings
- ATi5 NRAM settings
- ATi6 Link diagnostics summary

- /0* The modem returns a 3-digit product code. If you have a problem and call USRobotics' Technical Support Department, you may be asked for this product code.
- /1* The modem performs a checksum of its read only memory (ROM) and returns the result to the screen. This function is used only in factory testing. The modem should always read the same number.
- /2* The modem performs a test of its random access memory (RAM) and returns either the OK (0) or ERROR (4) result code, followed by OK when the test is completed. You may want to use this command as a checkpoint if the modem appears to be malfunctioning.
- /3* The modem returns the duration of the last call if set to K0. It displays the actual time if set to K1. See the description of the Kn command in Chapter 5.
- /4* The modem displays its current configuration. The illustration on the following page is an example.

```

ati4
USRobotics Courier HST Settings....

C=1 E=1 F=1 M=1 Q=0 V=1 X=1 B=1
BAUD=9600 PARITY=N WORDLEN=8
DIAL=PULSE ON HOOK TIMER

AA1 AB0 AC0 AD0 AE0 AF0 AG4
AH0 AP0 AR1 AS0 AV1

S00=001 S01=000 S02=043 S03=013
S04=010 S05=000 S06=002 S07=030
S08=002 S09=006 S10=007 S11=070
S12=050 S13=000 S14=001 S15=000
S16=000 S17=000 S18=000 S19=000
S20=000 S21=000 S22=017 S23=019

OK
    
```

**Figure 7.1—Sample Result of ATi4 Command**

- 15 The modem displays the configuration stored in nonvolatile random access memory (NRAM).

```

ati5
USRobotics Courier HST NRAM Settings....

DIAL=TONE M=1 X=1 F=1 B=1
BAUD=9600 PARITY=N WORDLEN=8

AA1 AB1 AC0 AD0 AE0 AF0 AG4
AH0 AP0 AR2 AS0 AV1

S02=043 S03=013 S04=010 S05=000
S06=002 S07=030 S08=002 S09=006
S10=007 S11=070 S12=050 S13=000
S19=000 S21=000 S22=017 S23=019

STORED PHONE #0: 1-312-982-5092
          #1:
          #2:
          #3:

OK
    
```

**Figure 7.2—Sample NRAM Settings Screen (ATi5)**

- 16 During a connection, the modem monitors and stores information about link operations. When the call is ended, you can request a diagnostic summary, as in the following example.

```

ati6

Chars sent           3669
Chars received      4249
Chars lost           0
Data blocks transmitted 438
Data blocks retransmitted 2
Retrans             0
Line Reversals      2

OK

```

**Figure 7.3—Sample Link Diagnostics Screen (ATI6)**

### S-REGISTER QUERY (Sr?)

This command allows you to view the contents of a particular S-Register, as in this example which requests the contents of register S0 ("On what ring will the modem answer?");

```
ATS0? : cr >
```

Most registers store values that can be user-defined. However, two registers that are not user-programmable can be queried for the following diagnostic information.

- S17** The reason for a Link Disconnect when two modems try to make an ARQ connection and fail, or when the remote modem disconnects from an ARQ session. S17 is used for debugging purposes. If you're having an ARQ-compatibility problem and call USRobotics' Technical Support Department, you may be asked to check S17.
- S20** The reason for a NO CARRIER result code when the modem is in either ARQ or Normal Mode. Reasons include user aborts (pressing <any key> during dialing), loss of carrier, and the automatic hangup that occurs when the modem is set to &M5 and calls a modem not operating under error control.

PHONE NUMBER  
QUERY (&Zn?)

At this command, the modem returns the phone number stored in NRAM at position *n*, as in the following example that includes a sample modem response:

```
AT&Z3? <cr>
5551234
```

HELP SCREENS

The Courier HST provides four Help screens: summaries of the basic AT command set, extended ampersand (&) command set, S-register functions, and Dial command options.

*Stop/Restart  
Display*

The following command stops the display. Hold down the Control key and type “S”:

```
<Ctrl>-S
```

To restart the display, use the same command or press <any key>.

*Cancel Display*

Either of the following commands cancels the display.

```
<Ctrl>-C
<Ctrl>-K
```

Basic Command  
Set (\$)

At AT\$, the Courier displays this command set summary:

AT\$	HELP, Extended Commands	In	n=5	NRAM Settings
A	Answer Call		n=6	Link Diagnostics
A/	Repeat Last Command	Xn	n=0	Call Duration Mode
Bn	n=0 CCITT Answer Sequence		n=1	Real Time Clock Mode
	n=1 Bell Answer Sequence	Mn	n=0	Speaker Off
Cn	n=0 Transmitter Off		n=1	Speaker On Until CD
	n=1 Transmitter On		n=2	Speaker Always On
Dn	Dial a Telephone Number		n=3	Speaker Off During Dial
	n=0..9#-TPR,:"W!()-	0		Return On-Line
DSn	Dial Stored Phone Number	Qn	n=0	Result Codes Sent
D\$	HELP, Dial Commands		n=1	Quiet (No Result Codes)
En	n=0 Do not echo Chars	Sr=n		Sets Register "r" to "n"
	n=1 echo Command Chars	Sr?		Query Register "r"
Fn	n=0 Half duplex	S\$		HELP, S Registers
	n=1 Full duplex	Vn	n=0	Numeric Responses
Hn	n=0 On Hook (Hang Up)		n=1	Verbal Responses
	n=1 Off Hook	Xn	n=0	Basic Result Codes
In	n=0 Product Code		n=1	Extended Result Codes
	n=1 Checksum		n=2-7	Advanced Result Codes
	n=2 RAM Test	Z		Software Reset
	n=3 Call Duration/Clock	>		Repeat Command String
	n=4 Current Settings	\$		HELP, Command Summary
OK				

Figure 7.4—Basic Commands HELP Screen

Extended  
Command  
Set (&\$)

At AT&\$, the Courier displays this summary of the ampersand command set:

```

AT&$
HELP, Extended Commands (CTRL-S to Stop, CTRL-C to Cancel)

&An n=0 Disable /ARQ Result Codes      &Mn n=0 Highest Link Speed
      n=1 Allow /ARQ Result Codes      n=1 300 bps      n=3 2400 bps
&Bn n=0 Variable DTE Speed              n=2 1200 bps    n=6 9600 bps
      n=1 Fixed DTE Speed              &Pn n=0 USA Pulse Dial
&F Load Factory Configuration          &Rn n=1 Ignore RTS
&Hn n=0 Disable TX data flow control    n=2 RX Data to DTE / RTS high
      n=1 CTS                          &Sn n=0 DSR always On
      n=2 Xon/Xoff                      n=1 Modem controls DSR
      n=3 CTS and Xon/Xoff              &W Store Current Configuration
&In n=0 Disable RX data flow control    &Yn n=0 Destructive Break
      n=1 Xon/Xoff                      n=1 Destructive/Expedited
      n=2 Xon/Xoff chars filtered        n=2 Nondestructive/Expedited
      n=3 HP Eng/Ack Host Mode          n=3 Nondestructive/Unexpedited
&Mn n=0 Normal Mode                    &Zn5 Store Phone Number
      n=4 ARQ/Normal Mode               &Zn7 Query Phone Number
      n=5 ARQ Mode

OK
    
```

Figure 7.5—Ampersand Commands HELP Screen

S-Register  
Functions (S\$)

At ATSS, the Courier displays a summary of the S-register functions:

```

ats$
HELP, S Register Functions (CTRL-S to Stop, CTRL-C to Cancel)

S0 Ring to Answer On                  S11 Touch Tone Spacing (msec)
S1 Counts # of Rings                  S12 Escape Code Time (1/50sec)
S2 Escape Code Char                   S13 Bit Mapped
S3 Carriage Return Char              S16 Test Modes
S4 Line Feed Char                    S17 LD Reason
S5 Backspace Char                    S19 Inactivity Timeout (min)
S6 Wait Time/Dial Tone (sec)          S20 Disconnect Reason
S7 Wait Time/Carrier (sec)            S21 Break Length
S8 Comma and Repeat Pause (sec)      S22 Xon Char
S9 Carrier Detect Time (1/10sec)     S23 Xoff Char
S10 Carrier Loss Time (1/10sec)

OK
    
```

Figure 7.6—S-Register HELP Screen

Dialing (D\$)      At ATD\$, the Courier displays this Dial command summary:

```
atd$
HELP, Dial Commands (CTRL-S to Stop, CTRL-C to Cancel)

0-9 Digits to Dial
*# Auxiliary Digits
T Tone Dialing
P Pulse Dialing
R Call an Originate Only Modem
, Pause
: Remain in Command Mode
" Used to Dial Alpha Phone #'s
W Wait for 2nd Dial Tone (X3-X6)
# Wait for an Answer (X3-X6)
! Flash Switch Hook

OK
```

**Figure 7.7—Dial Command HELP Screen**





## PART II. REFERENCE

APPENDIX A—Error/Flow Control Concepts	A-1
Overview	A-1
Throughput	A-1
MNP Service Classes	A-1
Error Detection/Retransmission	A-2
Flow Control	A-3
Example 1—Transmit Data	A-4
Example 2—Received Data	A-4
APPENDIX B—Summaries and Tables	B-1
The RS-232C Interface, with Pin Definitions	B-1.1
Front End Indicators	B-2.1
DIP Switch Summary	B-3.1
Default Settings	B-4.1
S-Register Summary	B-5.1
ASCII Chart	B-6.1
APPENDIX C—Alphabetical Command Summary	C-1
APPENDIX D—Problems and Solutions	D-1
If You Still Have Problems	D-3
APPENDIX E—Additional Operational Information	E-1
Using Both Voice and Data Communications	E-1.1
High Speed/Low Speed Protocol	E-2.1
Retrain Sequence	E-3.1
PBX, Dedicated Line, and Leased Line Operations	E-4.1
Hewlett Packard Installations	E-5.1
APPENDIX F—Technical Specifications	F-1
GLOSSARY	G-1
INDEX	



**OVERVIEW**

At 9600 bps, the Courier HST uses the USR-HST error control protocol, a proprietary protocol developed by USRobotics. At 2400/1200 bps, the modem uses the MNP error control protocol originally developed by Microcom, Inc. and now in the public domain. In USRobotics implementations, we use the general term ARQ (automatic repeat request) to denote error control at all three speeds.

Error-free data transmission is ensured through two features:

- error-detection and retransmission techniques;
- data buffering and flow control.

**NOTE:** As with all protocols, error control only works when the Courier HST connects with another modem that implements the HST protocol at 9600 bps or the MNP protocol at 2400/1200 bps.

**Throughput**

Chapter 3 offers recommended modem settings to gain maximum throughput at 9600 bps. Optimal throughput is about 1100 characters per second when the link speed is 9600 bps and the terminal transmits to the modem at 19.2k bps. The design of the HST protocol builds on and enhances previous protocols by integrating much of the additional error control information (overhead) within the data blocks instead of transmitting separate ARQ data.

For optimal throughput at 2400/1200 bps under MNP, see Service Class 3, below.

**MNP Service  
Classes**

At 2400/1200 the ARQ protocol implements one of three MNP service classes, as follows:

***Service Class 1***

This service class, often called Block Mode, supports half-duplex (one way at a time) transmission. The sending modem transmits a block of data and waits for an acknowledgment from the receiving modem before sending the next.

Service Class 1 is the slowest and is included because some computer equipment is restricted to either sending or receiving at any one time. This mode of operation is usually observed in communications between terminals rather than in terminal-to-computer or computer-to-computer links.

***Service Class 2***

This class, often called Stream Mode, supports full-duplex transmission in which data flows in both directions at the

same time. Throughput at Class 2, due to protocol overhead, achieves about 84% of the throughput of a normal modem, or approximately 202 characters per second (cps) at 2400 bps.

*Service Class 3*

Service Class 3 incorporates Class 2 and is more efficient. Modems sending at Service Class 3 strip the Start and Stop bits from the data characters and transmit the data across the link in bit format, as in synchronous transmission, rather than in character format. The receiving modem reinserts the Start and Stop bits for each character before passing the data to the receiving computer or terminal.

This procedure offsets the protocol overhead loss so that throughput is about 108% that of a normal modem. Under optimal conditions, two Class 3 modems operating at 2400 bps can exchange data at approximately 259 characters per second.

When the modems negotiate their MNP connection, each indicates its highest service level and they agree to operate at the highest level possible, Service Class 3, 2, or 1. The Courier HST indicates Class 3 in its MNP error-control parameter. If necessary, the Courier automatically drops back to meet the requirements of the other modem.

ERROR  
DETECTION  
RETRANS-  
MISSION

During an ARQ connection the transmitting modem divides the data it receives from the computer or terminal into blocks, and attaches header and trailer information. The result is called a *frame*, as shown in Figure A.1.



**Figure A.1—Transmission Frame**

Included in the header or trailer are a frame number and block-size information as well as a *frame-check* code. This last code is derived by the sending modem through an algorithm performed on all of the data in the frame. The technique is called *cyclic-redundancy checking (CRC)*.


The receiving modem performs the same computation and checks to see if its results match the received CRC code. If the results match, the receiving modem sends a positive acknowledgement to the sending modem. Meanwhile, the

sending modem keeps a copy of all frames it sends until each is positively acknowledged.

If the CRC codes don't match, the receiving modem initiates the *automatic repeat request (ARQ)* procedure. The receiving modem tells the sending modem which frame is in error, and doesn't accept any more frames until the frame in question is received correctly. The sending modem goes back to the specified frame, retransmits it, and continues from there. In this way the protocol protects against errors and also ensures that the data arrives in sequence.

## FLOW CONTROL

When flow control is enabled, the modem stores data in a *buffer*, as shown in Figure A.2, and monitors how full the the buffer is.



**Figure A.2—Flow Control Buffer**

The buffer is used to store data transmitted to the modem from the computer or terminal as well as data received over the data link. Separate commands instruct the modem for Transmit Data flow control (&Hn) and Received Data flow control (&In, &Rn). Chapter 4 contains instructions on when and how to use these commands.

### *Flow Control Examples*


The labels used in the following examples indicate the following devices:

*DTE Data Terminal Equipment*: devices that are the source or final destination of transmitted data, such as a personal computer, mainframe, or terminal.

*DCE Data Communications Equipment*: also called Circuit-Terminating Equipment, for our discussion indicates the modems that establish and otherwise control the phone connection (data link).

*Example 1—  
Transmit Data*

The `&Hn` command allows you to select software flow control, hardware flow control, or both. Under software flow control the modem sends the DTE the ASCII XON/XOFF characters described in Chapter 4. Under hardware control the modem raises or lowers the Clear to Send (CTS) signal via the RS-232C interface.



**Figure A.3—Transmit Flow Control**

Assume that there are disturbances on the line (line hits) and DCE2, the receiving modem, detects a transmitted frame error. DCE2 tells DCE1 to retransmit the frame and accepts no additional frames until it receives the affected frame correctly.

Meanwhile, the computer/terminal (DTE1) continues sending to DCE1, and data backs up in the buffer. As the buffer approaches capacity, DCE1 signals DTE1 to stop sending data. DCE1 also retransmits the specified frame and continues transmitting. When enough data is transmitted to half empty the buffer, DCE1 signals DTE1 to resume sending data.


As mentioned in Chapter 4, Transmit Data flow control is also essential if the DTE is set to send to the modem at a rate higher than the link rate.

*Example 2—  
Received Data*

It may be necessary or desirable to stop incoming data temporarily, for example, in order to review what's on the screen and take some kind of action. In the following diagram, the labels indicate operations when three different command options are used, as follows:

- `&I1` The user at DTE1 sends an XOFF command to the modem to have it stop passing on the received data. The command is also transmitted to the remote modem, which stops sending. When the user wants to receive more data, an XON command is sent to both modems to resume.

- &I2 The user sends the same XON/XOFF commands to the modem, but the modem doesn't pass them on to the remote modem. The reason is explained in Chapter 4.
- &R2 If DTE1 is a computer that supports the Request to Send (RTS) signal at the RS-232C interface, RTS is lowered to signal the modem to stop passing on received data.



**Figure A.4—Received Data Flow Control**

Be sure to review Chapters 3 and 4 before using the error/flow control commands.



**CONTENTS**

- B-1 The RS-232C Interface, with Pin Definitions
- B-2 Front End Indicators
- B-3 DIP Switch Summary
- B-4 Default Settings
- B-5 S-Register Summary
- B-6 ASCII Chart

**APPENDIX B-1**  
**THE RS-232C INTERFACE, WITH PIN DEFINITIONS**

**DESCRIPTION**

The RS-232C interface (often referred to without the "C") is a standard developed by the Electronic Industries Association (EIA). It defines the signals and voltages used when data is exchanged between a computer or terminal and a modem or serial printer. Data is transmitted between the devices via a cable with (typically) 25-pin connectors.

**PIN ASSIGNMENTS**

The entire standard covers many more functions than are used in most data communications applications. The pin assignments that are factory set in the Courier HST are shown in the following table.

<b>RS-232C INTERFACE PIN DEFINITIONS</b>			
Pin	Circuit	Function	Signal Flow
2	BA	Transmit Data	Terminal ← Modem
3	BB	Receive Data	Terminal → Modem
4	CA	Request to Send	Terminal ← Modem
5	CB	Clear to Send	Terminal → Modem
6	CC	Data Set Ready	Terminal → Modem
7	AB	Signal Ground	Terminal ↔ Modem
8	CF	Carrier Detect	Terminal → Modem
12	SCF	Speed Indicate	Terminal → Modem
20	CD	Data Terminal Ready	Terminal ← Modem
22	CE	Ring Indicate	Terminal → Modem

**NOTE:** Some computer/terminal equipment supports only a few of the RS-232C signal functions set in the Courier. *The minimum required for the modem to operate are Pins 2, 3, and 7, plus the Data Terminal Ready (DTR) override switch ON (DIP switch 1 DOWN).* If the DTR override is OFF, Pin 20 is also required. If the modem is set for hardware flow control of transmitted data (&H1), Pin 5 is required. If the modem is set for hardware flow control of received data (&R2), Pin 4 is required.

## APPENDIX B-2 FRONT END INDICATORS

Symbol	Meaning	Status
HS	High Speed	ON when the Courier HST is powered on or communicating with another modem at 9600 bps. OFF during data link negotiations at 2400 bps.
AA	Auto Answer/ Answer	ON when the Courier is in Auto Answer Mode and when online with a calling modem.
CD	Carrier Detect	ON when the CD override (DIP switch 6) is ON (DOWN). ON if DIP switch 6 is UP and the Courier receives a valid data signal (carrier) from a remote modem, indicating that data transmission is possible.
OH	Off Hook	ON when the Courier takes control of the phone line to establish a data link.
RD	Received Data	Flashes when a data bit is received by the Courier from the phone line, or when the modem is sending result codes to the terminal or computer.
SD	Send Data	Flashes when a data bit is sent to the Courier by the terminal or computer.
TR	Terminal Ready	ON when the DTR override (DIP switch 1) is ON (DOWN). ON if DIP switch 1 is UP and the modem receives a Data Terminal Ready signal from the terminal or computer via RS-232C Pin 20.
MR	Modem Ready/ Power	ON when the Courier is powered on.
RS	Request to Send	ON when the Courier is powered on if your computer supports RTS (Pin 4) on the RS-232C interface.*
CS	Clear to Send	ON until the modem lowers CTS (Pin 5) on the RS-232C interface when Transmit Data hardware flow control is enabled.
ARQ	Error Control	Automatic Repeat Request. ON when the Courier is set to &M4 or &M5 and successfully connects with another modem under error control.
AL	Analog Loopback	ON when the modem is in Analog Loopback Self-Test Mode.

\* If RTS is supported and the Courier is set to &R2 for Received Data hardware flow control, the RS indicator goes OFF when the computer lowers RTS.

**APPENDIX B-3  
DIP SWITCH SUMMARY**

**PURPOSE** The Courier's DIP switches, located at the rear of the modem, are for adapting the modem to your equipment and personal requirements. You may also want to experiment and review your computer or terminal documentation as necessary.

Some users are able to move a single switch with a finger tip. If this doesn't work for you, use a toothpick or other small instrument.

**OPERATIONS** The DIP switch settings are power-on defaults, read by the Courier when it is turned on. If changed when the modem is on, switches 2-5 and 9 require the ATZ (software reset) command to initiate the new settings. The remaining (hardware) switches are automatically operative when set UP or DOWN.

**DIP SWITCHES: UP = OFF (OPEN), DOWN = ON (CLOSED)**

<b>Switch</b>	<b>Factory Setting</b>	<b>Function</b>
1	DOWN	Data Terminal Ready Override UP DTR normal; RS-232C Pin 20 controls modem DOWN DTR always ON (override)
2	UP	Verbal/Numeric Result Codes UP Verbal (word) messages DOWN Numeric codes
3	DOWN	Result Code Display UP Quiet Mode, no display DOWN Result codes displayed
4	UP	Command Mode Local Echo UP Keyboard commands displayed DOWN Display of commands suppressed
5	DOWN	Auto Answer UP Modem answers on first ring DOWN Auto Answer suppressed
6	DOWN	Carrier Detect Override UP RS-232C Pin 8 indicates when modem is online and a carrier data signal is present DOWN Carrier Detect signal always ON (override)

Switch	Setting	Function
7	UP	Single/Multiple Phone Installation UP Single phone line connection (RJ11 jack) DOWN Multiple phone installations (RJ12 or RJ13 jack); when the modem goes off hook the A/A1 leads on the RJ12 or RJ13 connector are shorted and the extension light goes on, indicating that the line is busy
8	DOWN	Command Set Recognition UP Command set recognition disabled (Dumb Mode) DOWN Normal operations (Smart Mode)
9	DOWN	Normal Mode Escape Code ( + + + ) Operations UP When escape code is sent, modem hangs up, returns to Command Mode, displays NO CARRIER DOWN When escape code is sent, modem retains connection, returns to Command Mode, displays OK  NOTE: Under error control, modem always hangs up at + + + .
10	UP	Power-on Software Defaults UP Load from NRAM DOWN Load factory settings from ROM
Quad Switch	UP	RS-232C Modem/Terminal Interface UP Normal assignments: Pin 2—terminal to modem; Pin 3—modem to terminal DOWN Alternate assignments: Pin 2—modem to terminal; Pin 3—terminal to modem  <i>The need to change this setting is rare. Carefully review your computer or terminal documentation before turning this switch ON.</i>

**APPENDIX B-4  
DEFAULT SETTINGS**

**USER-  
PROGRAM-  
MABLE  
DEFAULTS**

You can create your own default configuration and store it in nonvolatile random access memory (NRAM) using the &W command described in Chapter 5. Your defaults are then loaded into random access memory (RAM) as long as DIP switch 10 is UP when you power on the modem. To view your NRAM settings at any time, use the AT15 command.

The following tables list the options stored in NRAM. If DIP switch 10 is DOWN at power on, the factory settings listed in the table are loaded instead. The first time the modem is turned on, the NRAM settings are the same as the factory settings.

<b>NRAM Options</b>	<b>Factory Setting</b>	
Normal/error control modes	&M4	Normal/ARQ
Display of error-control response codes	&A1	Enabled
Transmit data flow control	&H0	Disabled
Received data software flow control	&I0	Disabled
Received data hardware flow control	&R1	Ignore RTS
Terminal-to-modem speed	&B0	Follow connection rate
Link speed (modem to modem)	&N0	Variable link operations
Data Set Ready (DSR) signal	&S0	Override
Stored telephone number	&Z0-3 = 0	Blank
Tone/Pulse dialing	P	Pulse dial
Online local echo	F1	Echo OFF
Speaker control	M1	ON during dial through connect
Result code sets	X1	Extended
Pulse dial make/break ratio	&P0	N. American
U.S./CCITT answer tone	B0	N. American
Break handling	&Y1	Clear buffer, send Break immediately
Parity setting detected from AT command	—	Even parity

<b>NRAM S-Register Options</b>	<b>Factory Setting</b>
Escape code character, ASCII	S2 = 43
Carriage Return character, ASCII decimal	S3 = 13
Line Feed character, ASCII decimal	S4 = 10
Backspace character, ASCII decimal	S5 = 8
Dial wait-time, sec.	S6 = 2
Carrier wait-time, sec.	S7 = 30
Dial pause/reexecute time, sec.	S8 = 2
Carrier Detect time, 1/10th sec.	S9 = 6
Carrier loss wait-time, 1/10th sec.	S10 = 7
Touch-Tone duration, spacing, msec.	S11 = 70
Escape code guard time, 1/50th sec.	S12 = 50
Bit-mapped functions, S-Register 13	S13 = 0
Inactivity/hang up timer, S-register 19	S19 = 0
Received break length, 10-msec. units	S21 = 10
XON character, ASCII	S22 = 17
XOFF character, ASCII	S23 = 19

**APPENDIX B-5  
S-REGISTER SUMMARY**

**USAGE** The default values are those users typically require. Change the settings with the `ATSr=n` command, where *r* is the register and *n* is a decimal value from 0–255:

```
ATS13=8 <cr>
```

The modem does not perform a value-range check. A value you select may not work with some equipment, and you'll have to readjust the setting.

To display the contents of a register, use `ATSr?` as in this example:

```
ATS20? <cr>
```

<b>Register</b>	<b>Default</b>	<b>Function</b>
S0	See DIP Switch 5	Sets the number of rings on which to answer when in Auto Answer Mode. Default = 1, equivalent of DIP switch 5 UP. S0=0 or DIP switch 5 DOWN (factory setting) suppresses Auto Answer.
S1	0	Counts and stores the number of rings from an incoming call.
S2	43	Stores the ASCII decimal code for the escape code character. Default character is ``+'. A value of 128–255 disables the escape code.
S3	13	Stores the ASCII decimal code for the Carriage Return character.
S4	10	Stores the ASCII decimal code for the Line Feed character.
S5	8	Stores the ASCII decimal code for the Backspace character. A value of 128–255 disables the Backspace key's delete function.
S6	2	Sets the number of seconds the modem waits before dialing. If set to X2, X4, X6, or X7, the modem ignores this register and dials as soon as it detects a dial tone (fast dials).
S7	30	Sets the number of seconds the modem waits for a carrier. May be set for much longer duration if, for example, the modem is originating an international connection.
S8	2	Sets the duration, in seconds, for the pause (.) option in the Dial command and the pause between command reexecutions (> and A> commands).

Register	Default	Function																											
S9	6	Sets the required duration, in tenths of a second, of the remote modem's carrier signal before recognition by the Courier (Carrier Detect Time).																											
S10	7	Sets the duration, in tenths of a second, that the modem waits after loss of carrier before hanging up.																											
S11	70	Sets the duration and spacing, in milliseconds, of dialed Touch-Tones.																											
S12	50	Sets the duration, in fiftieths of a second, of the guard time for the escape code sequence.																											
S13	0	Bit-mapped register. Select the bit(s) you want on, and set S13 to the total of the values in the "Value" column. For example, ATS13=20 enables bits 2 (value = 4) and 4 (value = 16). <table border="1" data-bbox="390 694 1067 1241"> <thead> <tr> <th>Bit</th> <th>Value</th> <th>Result</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1</td> <td>Reserved</td> </tr> <tr> <td>1</td> <td>2</td> <td>Reverse normal Auto Answer operation: on incoming RING, enter Originate Mode and look for Answer tone</td> </tr> <tr> <td>2</td> <td>4</td> <td>Disable 250 msec. pause before result code display</td> </tr> <tr> <td>3</td> <td>8</td> <td>When DTR goes from low to high, Auto Dial the number stored in NRAM at position 0</td> </tr> <tr> <td>4</td> <td>16</td> <td>At power on or reset, Auto Dial the number stored in NRAM at position 0</td> </tr> <tr> <td>5</td> <td>32</td> <td>Reserved</td> </tr> <tr> <td>6</td> <td>64</td> <td>Disable MNP Service Class 3 (used for testing Service Class 2)</td> </tr> <tr> <td>7</td> <td>128</td> <td>Watchdog hardware reset, same as power on (used in factory testing)</td> </tr> </tbody> </table>	Bit	Value	Result	0	1	Reserved	1	2	Reverse normal Auto Answer operation: on incoming RING, enter Originate Mode and look for Answer tone	2	4	Disable 250 msec. pause before result code display	3	8	When DTR goes from low to high, Auto Dial the number stored in NRAM at position 0	4	16	At power on or reset, Auto Dial the number stored in NRAM at position 0	5	32	Reserved	6	64	Disable MNP Service Class 3 (used for testing Service Class 2)	7	128	Watchdog hardware reset, same as power on (used in factory testing)
Bit	Value	Result																											
0	1	Reserved																											
1	2	Reverse normal Auto Answer operation: on incoming RING, enter Originate Mode and look for Answer tone																											
2	4	Disable 250 msec. pause before result code display																											
3	8	When DTR goes from low to high, Auto Dial the number stored in NRAM at position 0																											
4	16	At power on or reset, Auto Dial the number stored in NRAM at position 0																											
5	32	Reserved																											
6	64	Disable MNP Service Class 3 (used for testing Service Class 2)																											
7	128	Watchdog hardware reset, same as power on (used in factory testing)																											
S14		Reserved.																											
S15		Reserved.																											
S16	0	Modem self-test. See Chapter 2 for test procedures. <table border="1" data-bbox="413 1397 860 1562"> <tbody> <tr> <td>0</td> <td>Data Mode (no testing)</td> </tr> <tr> <td>1</td> <td>Analog Loopback</td> </tr> <tr> <td>2</td> <td>Dial Test</td> </tr> <tr> <td>4</td> <td>Test Pattern</td> </tr> <tr> <td>5</td> <td>Analog Loopback with Test Pattern</td> </tr> </tbody> </table>	0	Data Mode (no testing)	1	Analog Loopback	2	Dial Test	4	Test Pattern	5	Analog Loopback with Test Pattern																	
0	Data Mode (no testing)																												
1	Analog Loopback																												
2	Dial Test																												
4	Test Pattern																												
5	Analog Loopback with Test Pattern																												

<b>Register</b>	<b>Default</b>	<b>Function</b>
S17	0	Stores the reason for a received ARQ Link Disconnect. May be requested by Technical Support if you're having a problem connecting in ARQ mode with another ARQ-mode modem. At ATS17? the modem returns one of the following codes: <ul style="list-style-type: none"><li>1 Received data unit other than link request</li><li>2 Incompatible protocol level</li><li>3 Unknown parameters in link request</li><li>4 Remote modem retry timeout (Max. 12 tries)</li><li>5 Inactivity timeout</li><li>6 Destination user not found</li><li>254 Peer protocol error</li><li>255 User-initiated disconnect</li></ul>
S18		Reserved.
S19	0	Sets the duration, in minutes, for the Inactivity Timer. The timer is activated when there is no activity on the phone line. At the timeout the Courier hangs up.
S20	0	Stores the reason for the NO CARRIER result code. At ATS20? the modem returns one of the following codes: <ul style="list-style-type: none"><li>0 Key press abort</li><li>1 DTR dropped</li><li>2 Escape code ( + + + ) issued</li><li>3 Loss of Carrier</li><li>4 Inactivity timeout</li><li>5 Automatic hangup with ARQ incompatibility (&amp;M5 Mode)</li><li>6 ARQ Retry timeout (Max. 12 tries)</li><li>7 ARQ Received Link Disconnect (See S17)</li></ul>
S21	10	Sets, in 10-millisecond units, the length of Breaks sent from the modem to the local terminal.
S22	17	Stores the ASCII decimal code for the XON character.
S23	19	Stores the ASCII decimal code for the XOFF character.

APPENDIX B-6  
ASCII CHART

ASCII CHART											
DEC	HEX	CHAR	DEC	HEX	CHAR	DEC	HEX	CHAR	DEC	HEX	CHAR
00	00	NUL	32	20	SP	64	40	@	96	60	`
01	01	SOH	33	21	!	65	41	A	97	61	a
02	02	STX	34	22	"	66	42	B	98	62	b
03	03	ETX	35	23	#	67	43	C	99	63	c
04	04	EOT	36	24	\$	68	44	D	100	64	d
05	05	ENQ	37	25	%	69	45	E	101	65	e
06	06	ACK	38	26	&	70	46	F	102	66	f
07	07	BEL	39	27	'	71	47	G	103	67	g
08	08	BS	40	28	(	72	48	H	104	68	h
09	09	HT	41	29	)	73	49	I	105	69	i
10	0A	LF	42	2A	*	74	4A	J	106	6A	j
11	0B	VT	43	2B	+	75	4B	K	107	6B	k
12	0C	FF	44	2C	,	76	4C	L	108	6C	l
13	0D	CR	45	2D	-	77	4D	M	109	6D	m
14	0E	SO	46	2E	.	78	4E	N	110	6E	n
15	0F	SI	47	2F	/	79	4F	O	111	6F	o
16	10	DLE	48	30	0	80	50	P	112	70	p
17	11	XON	49	31	1	81	51	Q	113	71	q
18	12	DC2	50	32	2	82	52	R	114	72	r
19	13	XOFF	51	33	3	83	53	S	115	73	s
20	14	DC4	52	34	4	84	54	T	116	74	t
21	15	NAK	53	35	5	85	55	U	117	75	u
22	16	SYN	54	36	6	86	56	V	118	76	v
23	17	ETB	55	37	7	87	57	W	119	77	w
24	18	CAN	56	38	8	88	58	X	120	78	x
25	19	EM	57	39	9	89	59	Y	121	79	y
26	1A	SUB	58	3A	:	90	5A	Z	122	7A	z
27	1B	ESC	59	3B	;	91	5B	[	123	7B	{
28	1C	FS	60	3C	<	92	5C		124	7C	
29	1D	GS	61	3D	=	93	5D	]	125	7D	}
30	1E	RS	62	3E	>	94	5E	^	126	7E	~
31	1F	US	63	3F	?	95	5F	_	127	7F	DEL



## APPENDIX C

### ALPHABETICAL COMMAND SUMMARY

Additional command summaries are on the bottom panel of the modem and in the Quick-Reference Card.

#### Requirements

1. Type commands in either upper or lower case.
2. All commands except A/, A> and + + + are preceded by the AT prefix and are executed with the Enter/Carriage Return key (<cr>).
3. Command length = 40 characters maximum. The modem doesn't count the AT prefix, Carriage Return character, or spaces. It counts but doesn't act on punctuation such as hyphens and parentheses.
4. A missing numeric parameter is assumed to be zero, as in the command to hang up: ATH <cr> is the equivalent of ATH0 <cr>.

#### BASIC COMMAND SET

Command/ Options	Function
&	See the Extended Command Summary that follows this Basic Set.
A	Force Answer Mode when the modem hasn't received an incoming call.
A/	Reexecute the last issued command one time. A/ doesn't take the AT prefix or a Carriage Return.
A>	Reexecute the last issued command continuously until canceled by pressing <any key>. Dial strings are reexecuted ten times after which execution terminates. A> doesn't take the AT prefix or a Carriage Return.
<Any key>	Terminate current dialing operation resulting from an issued Dial command; terminate Repeat mode (> or A>).
AT	Attention: lets the modem know commands are being issued to it. <i>Must</i> precede all other commands except A/, A> and + + +.
Bn	U.S./CCITT answer sequence.
B0	CCITT (overseas) answer sequence.
B1	U.S. answer sequence (Default).

<i>Cn</i>	Transmitter enabled/disabled.
<i>C0</i>	Transmitter disabled; receive-only condition.
<i>C1</i>	Transmitter enabled (Default).
<i>D</i>	Dial the number that follows and enter Originate Mode. Optional parameters:
<i>P</i>	Pulse dial (Default).
<i>T</i>	Touch-Tone dial.
<i>,</i>	(Comma) Pause for 2 seconds.
<i>;</i>	Return to Command Mode after dialing.
<i>“</i>	Dial the letters that follow.
<i>!</i>	Transfer call (flash switch-hook).
<i>W</i>	Wait for second dial tone (with X3 or higher).
<i>@</i>	Wait for an answer (with X3 or higher).
<i>R</i>	Reverse frequencies.
<i>DSn</i>	Dial the phone number stored in NRAM at position <i>n</i> ( <i>n</i> = 0–3).
<i>En</i>	Command Mode local echo (display) of keyboard commands ON/OFF. (DIP switch 4 is factory set to Command Mode echo ON.)
<i>E0</i>	Local echo OFF.
<i>E1</i>	Local echo ON.
<i>Fn</i>	Online local echo of transmitted data ON/OFF. Sometimes referred to as the Duplex setting.
<i>F0</i>	Local echo ON. Sometimes called Half Duplex. Modem sends a copy to your screen of data it sends to the re- mote system.
<i>F1</i>	Local echo OFF (Default). Sometimes called Full Duplex. Receiving system may send a remote echo of data it receives.
<i>Hn</i>	On/off hook control.
<i>H0</i>	Hang up (go on hook).
<i>H1</i>	Go off hook.

---

<i>In</i>	Inquiry.
<i>I0</i>	Display product code.
<i>I1</i>	Display results of ROM checksum.
<i>I2</i>	Display results of RAM test.
<i>I3</i>	Display call duration or real time (see <i>Kn</i> ).
<i>I4</i>	Display current modem settings.
<i>I5</i>	Display NRAM settings.
<i>I6</i>	Display Link diagnostics.
<i>Kn</i>	Modem clock operation: Call-duration or Real-time Mode.
<i>K0</i>	Return call duration at ATi3 (Default).
<i>K1</i>	Return actual time at ATi3. Clock is set using ATi3 = HH:MM:SS K1.
<i>Mn</i>	Monitor (speaker) control.
<i>M0</i>	Speaker always OFF.
<i>M1</i>	Speaker ON until carrier is established (Default).
<i>M2</i>	Speaker always ON.
<i>M3</i>	Speaker ON after last digit dialed and until carrier is established.
<i>O</i>	Return online after command execution.
<i>P</i>	Pulse dial (Default).
<i>Qn</i>	Quiet Mode: result codes displayed/suppressed. (DIP switch 3 is factory set to display result codes.)
<i>Q0</i>	Result codes displayed.
<i>Q1</i>	Result codes suppressed ("quiet").
<i>Sr = n</i>	S-register commands: <i>r</i> is any S-register; <i>n</i> must be a decimal number between 0 and 255.
<i>Sr?</i>	Query register <i>r</i> .
<i>T</i>	Tone dial.

- Vn** Return result codes in words or numbers (Verbal/Numeric Mode). (DIP switch 2 is factory set to verbal result codes.)
- V0** Numeric Mode.
- V1** Verbal Mode.
- Xn** Result code set options. Use the following table (Default = X1, Extended set, codes 0-5, 10 and 13).

<b>RESULT CODES OPTIONS TABLE</b>								
Commands								
	X0	X1	X2	X3	X4	X5	X6	X7
<b>Result codes</b>								
0/OK	X	X	X	X	X	X	X	X
1/CONNECT	X	X	X	X	X	X	X	X
2/RING	X	X	X	X	X	X	X	X
3/NO CARRIER	X	X	X	X	X	X	X	X
4/ERROR	X	X	X	X	X	X	X	X
5/CONNECT 1200		X	X	X	X	X	X	X
6/NO DIAL TONE			X		X		X	X
7/BUSY				X	X	X	X	X
8/NO ANSWER				X	X	X	X	X
9/Reserved								
10/CONNECT 2400		X	X	X	X	X	X	X
11/RINGING						X	X	X
12/VOICE						X	X	
13/CONNECT 9600		X	X	X	X	X	X	X
<b>Functions</b>								
Adaptive Dialing			X	X	X	X	X	X
Wait for 2nd Dial Tone (W)				X	X	X	X	X
Wait for Answer (@)				X	X	X	X	X
Fast Dial		X		X		X	X	X

**NOTE:** Depending on the &A setting, the following result codes are enabled/disabled. The default is &A1, /ARQ codes enabled.

- 15 CONNECT 1200/ARQ
- 16 CONNECT 2400/ARQ
- 17 CONNECT 9600/ARQ



**EXTENDED COMMAND SET**

<b>Command/ Options</b>	<b>Function</b>
&An	Enable/disable /ARQ result codes.
&A0	Suppress /ARQ result codes.
&A1	Display /ARQ result codes (Default).
&Bn	Data Rate, terminal-to-modem (DTE/DCE) variable or fixed.
&B0	DTE/DCE rate follows connection rate (Default).
&B1	DTE/DCE fixed at the DTE setting. Allowable rates are 19.2k, 9600, 2400, 1200, 300 bps.
&F	Load factory (ROM) settings into random access memory (RAM).
&Hn	Transmit Data flow control.
&H0	Flow control disabled (Default).
&H1	Hardware (CTS, Pin 5) flow control.
&H2	Software (XON/XOFF) flow control.
&H3	Hardware and software control.
&In	Received Data software flow control.
&I0	Flow control disabled (Default).
&I1	XON/XOFF to local modem and remote system.
&I2	XON/XOFF to local modem only.
&I3	Host Mode, Hewlett Packard protocol.
&I4	Terminal Mode, Hewlett Packard protocol.
&Mn	Normal or Error Control Modes.
&M0	Normal Mode.
&M1	Reserved.
&M2	Reserved.
&M3	Reserved.
&M4	Normal/ARQ Mode—Normal if ARQ connection cannot be made (Default).
&M5	ARQ Mode—hang up if ARQ connection cannot be made.

---

<b>&amp;Nn</b>	Link Data Rate (DCE/DCE) variable or fixed. With fixed link rate, modem hangs up if called or calling modem is operating at a different rate.
<b>&amp;N0</b>	Normal link operations; negotiate highest possible link rate with remote modem (Default).
<b>&amp;N1</b>	300 bps.
<b>&amp;N2</b>	1200 bps.
<b>&amp;N3</b>	2400 bps.
<b>&amp;N4</b>	Reserved.
<b>&amp;N5</b>	Reserved.
<b>&amp;N6</b>	9600 bps.
<b>&amp;Pn</b>	Pulse dialing make/break ratio.
<b>&amp;P0</b>	Use North American make/break ratio (Default).
<b>&amp;P1</b>	Use British Commonwealth make/break ratio (excluding Canada).
<b>&amp;Rn</b>	Received Data hardware flow control (RTS, Pin 4).
<b>&amp;R0</b>	Reserved.
<b>&amp;R1</b>	Ignore RTS (Default).
<b>&amp;R2</b>	Received data output to terminal on RTS high; used only if terminal supports RTS (Pin 4).
<b>&amp;Sn</b>	Data Set Ready (DSR, Pin 6) override.
<b>&amp;S0</b>	DSR override, always ON (Default).
<b>&amp;S1</b>	Modem controls DSR.
<b>&amp;W</b>	Write current settings to nonvolatile random access memory (NRAM).
<b>&amp;Yn</b>	Break handling. Destructive Breaks clear the buffer; expedited Breaks are sent immediately to the remote system.
<b>&amp;Y0</b>	Destructive, don't send Break.
<b>&amp;Y1</b>	Destructive, expedited (Default).
<b>&amp;Y2</b>	Nondestructive, expedited.
<b>&amp;Y3</b>	Nondestructive, unexpedited; modem sends Break in sequence with data received from terminal equipment.

**&Zn = s** Write the following Dial string (*s*) to NRAM at position *n* (*n* = 0–3). Maximum length of *s* is 36 characters.

**&Zn?** Display the phone number stored in NRAM at position *n*.

You may occasionally encounter one of the problems listed here. They are divided into two categories: before and during the exchange of user information over the data link.

---

PROBLEM	SUGGESTED SOLUTION
---------	--------------------

---

PROBLEM	SUGGESTED SOLUTION
<b>Before Establishment of the Data Link</b>	

---

*Your modem . . .*

Doesn't answer the phone or go "off hook" to dial a number

Check to make sure your computer or terminal is providing a positive voltage on pin 20 (Data Terminal Ready) of the RS-232C connector. ➤ See Appendix B-3, DIP switch 1.

Doesn't respond OK when you type AT <cr>

1. Make sure you're typing in either upper case or lower case letters, not a combination, and that you type a Carriage Return.
2. If you're using a computer, make sure it is in Terminal Mode.
3. Check to see that your terminal or software is set to the correct bit rate and word length (7 bits with or without a parity bit, or 8 bits and no parity). If you're using a computer, make sure your software is set to the correct communications port.
4. Check that DIP switch 3 is DOWN, for result code display, and that DIP switch 2 is UP, for verbal result codes. If not, change the switch(es) and issue ATZ <cr>. Or issue whichever of these commands is needed:

ATQ0 <cr> (to display the message)

ATV1 <cr> (to display a verbal message)

5. Your machine may require the Carrier Detect override (DIP Switch 6 DOWN), but you've changed the factory setting. Check Appendix B-3.
6. A rare condition is that your terminal/computer reverses the send/receive functions of RS-232C pins 2 and 3.  
➤ See Appendix B-1, Appendix B-3, Quad switch, and your equipment documentation.

PROBLEM

SUGGESTED SOLUTION

---

Before Establishment of the Data Link

---

*Your computer . . .*

Reacts as though a data link has been established, but no call has been received

When the modem is in Answer Mode, acts as if a Carriage Return has been entered, but nothing has been typed at the keyboard

DIP Switch 6 is set DOWN at the factory for Carrier Detect override, but your system may be reacting to improper signals received on pin 8 of the RS-232C connector. Set DIP switch 6 UP (OFF).

Your software may be misreading signals from the modem as it automatically sends a Carriage Return and a Line Feed before and after the RING and CONNECT messages. Entering the Quiet Mode command, ATQ1 <cr>, should solve the problem.

*Both modems . . .*

Exchange carrier signals, but fail to establish a communications link

1. Check to make sure the proper bit rate, word length, parity and number of Stop bits have been selected.
2. If that doesn't correct the problem, it's likely that the quality of the phone connection is poor and that the other modem is missing the signals your modem is transmitting. The variable quality of phone line connections may be due to any number of conditions in the phone service's equipment or the current environment. Try several calls, and if you still can't get through, try calling another modem. If the second modem accepts your call, the problem lies with the modem you first tried to call.
3. Make sure the modem at the other end of the line is USR-HST compatible at 9600 bps, V.22bis-compatible at 2400 bps, Bell 212A-compatible at 1200 bps, or Bell 103-compatible at 300 bps. These are the common signaling standards for full duplex dial-up network transmission in the U.S.

---

PROBLEM	SUGGESTED SOLUTION
---------	--------------------

---

During Data Transfer

---

*Your screen displays . . .*

Only brackets

Check to make sure both modems are at the same bit rate, word length, parity and number of Stop bits. If the settings are correct, the problem may be with the phone line. Try the following measures:

1. Try placing the call again. The phone company routes even local calls differently each time you call.
2. Try calling a different modem to see if the problem persists. (However, if it does, the problem may still be with the phone line.)
3. If you are using a long-distance service and the problem persists, you might try using a different service.

Random (garbage) characters

Make sure both modems are set at the same bit rate, word length, parity, and number of Stop bits.

Double characters

The modem's online local echo is probably ON. If the modem's in Normal Mode, return it to Command Mode (use + + +) when it's convenient, and then type:

**ATF1 <cr>**

If the modem's in an ARQ connection the only alternatives are to put up with the problem until you disconnect or to hang up (type + + +), issue the ATF1 command, and call again.

---

**IF YOU  
STILL HAVE  
PROBLEMS**

The problems described above are by far the most common ones that users encounter. If the suggestions we've given don't clear up your difficulties, try the following:

1. Review the manual carefully to see if you've missed something.
2. Call or visit your dealer. Chances are your dealer will be able to give you the assistance you need. This is much more efficient and time-saving than returning the modem to USRobotics.

3. If your dealer can't clear up your difficulties, call the USRobotics Technical Support Department at 800/982-5151 (in Illinois, 312/982-5151). Our Service Representatives will be happy to give you assistance over the phone Monday through Friday from 8:30 a.m. to 5 p.m. (Central Time Zone).
4. If necessary, the Service Representative you talk to may give you a Return Materials Authorization (RMA) number. *Modems without an RMA number will not be accepted.*
5. If you do return the modem to us, please follow this procedure—
  - a. Ship the unit, postage paid, in its original container. If the original container is not available, pack the modem carefully in a strong box of corrugated cardboard with plenty of packing material.
  - b. Be sure to include your RMA number inside the package, along with your name and address. *Put your return address and your RMA number on the shipping label as well.*
  - c. Ship the well-packed modem to the following address.

Technical Support Department  
USRobotics, Inc.  
8100 North McCormick Boulevard  
Skokie, Illinois 60076
  - d. Please note that USRobotics will not accept packages sent COD, so be sure to send the modem postage paid.
  - e. USRobotics will repair your modem and return it to you via United Parcel Service.

CONTENTS

- E-1 Using Both Voice and Data Communications
- E-2 High Speed/Low Speed Protocol
- E-3 Retrain Sequence
- E-4 PBX, Dedicated Line, and Leased Line Operations
- E-5 Hewlett Packard Installations

APPENDIX E-1  
USING BOTH VOICE AND DATA COMMUNICATIONS

When you assemble the Courier, you have the option of plugging your phone into the second modular jack of the modem so it's available for voice calls. You can also use the phone to synchronize communications with another user whose modem uses the AT command set, such as a USRobotics or USRobotics-compatible modem.

PREPARATION

First call the other user to establish the bit rate, parity, word length and number of Stop bits the other person's modem accepts. Then both of you can turn the call over to your modems.

COMMANDS

1. Without hanging up the phone, have your modem go off hook in Originate Mode. Type the following command:

`ATD <cr>`

**NOTE:** Be sure the modem is not set to X2, X4, X6, or X7, or it will return the NO DIAL TONE result code and hang up.

2. The other party should then have the remote modem go off hook in Answer Mode. The following command is used to do this:

`ATA <cr>`

3. Now both of you can hang up your respective phones while the two modems establish the data link. They will maintain the link until one of you gives your modem a command to disconnect.

Either party's device can be the originate or answer modem: it doesn't matter who made the phone call. But one modem must first enter Originate Mode and the other then enter Answer Mode. You and the other party, therefore, must agree on which command, ATD or ATA, you will each use.

**NOTE:** It may happen that spurious "garbage" characters will appear on the screen when you hang up the phone. You can avoid these by hanging up the phone as soon as you hear the modem go off hook, during the one or two seconds it takes the two modems to establish the link.

## OVERVIEW

This appendix is intended for those users who want to try programming their computers to switch bit rates to match the Courier HST's connection rate. The material here applies only when the modem is set for variable rates at both the DTE (computer) and link interfaces, &B0 and &N0, respectively.

In both Originate or Answer Modes, if the link rate is set to &N0 the Courier HST negotiates with the remote modem to connect at the highest possible rate. In addition, if the modem is set to the Extended or Advanced result codes (X1 or higher) it signals the DTE with one of the following result codes or, unless the call is at 300 bps, an /ARQ Mode equivalent:

CONNECT	(300 bps)
CONNECT 1200	(1200 bps)
CONNECT 2400	(2400 bps)
CONNECT 9600	(9600 bps)

The modem sends the result code at its previous rate. Then it switches to the new connection rate.

If your computer doesn't switch rates and you want to program it to do so, use the example on the next page as a guide. It demonstrates the occurrence of the CONNECT codes in the connection sequence, so that recognition of the codes can be used to switch the computer. The example uses a sequence of incoming calls, but the codes apply to Originate Mode connections as well.

The example assumes the following settings:

- Software: initially 9600 or 19.2k bps, allowing the full range of link rates:  
9600/2400/1200/300 bps
- Modem: X1 or higher (rate-specific CONNECT codes)  
&B0 (variable DTE rate)  
&N0 (variable link rate)

Example

Action	Modem Response	DTE/DCE Rate
1. Power on.		9600
2. 300-bps call comes in.	RING	9600
	CONNECT	9600
3. Data link is established. Data transfer takes place.		300
4. Data session is over. Call is ended; loss of carrier.	NO CARRIER	300
5. 2400-bps call comes in.	RING	300
	CONNECT 2400	300
6. Data link is established. Data transfer takes place.		2400
7. Data session is over. Call is ended; loss of carrier.	NO CARRIER	2400
8. 9600-bps call comes in.	RING	2400
	CONNECT 9600	2400
9. Data link is established. Data transfer takes place.		9600
10. Data session is over. Call is ended; loss of carrier.	NO CARRIER	9600

Explanation

1. The modem is powered on and is operating at 9600 bps. If the software is then set to 19.2k bps and an AT command sent, the DTE/DCE rate would be 19.2k bps.
2. A 300-bps modem calls. The Courier senses the incoming signal and sends the messages RING and CONNECT to the computer. These messages are sent at 9600 (or 19.2k) bps, the current rate.
3. Since the Courier responds CONNECT, rather than CONNECT 1200, 2400, or 9600, the computer switches to 300 bps. The modem automatically shifts to 300 bps to accept the data from the incoming call.

4. The 300-bps data session is terminated; the modem sends the message NO CARRIER at 300 bps.
5. A 2400-bps call comes in. The modem responds RING and CONNECT 2400. These message are sent at the current bit rate of 300 bps.
6. The computer, receiving the CONNECT 2400 message, adjusts accordingly to the higher bit rate. The modem also shifts to 2400 bps.
7. The 2400-bps data session is terminated; the modem sends the message NO CARRIER at 2400 bps.
8. A 9600-bps call comes in. The modem responds RING and CONNECT 9600. These message are sent at the current bit rate of 2400 bps.
9. The computer, receiving the CONNECT 9600 message, adjusts accordingly to the higher bit rate. The modem also shifts to 9600 bps.
10. The 9600-bps data session is terminated; the modem sends the message NO CARRIER at 9600 bps.

Keep in mind that whether or not your computer adjusts to these rate changes, the Courier automatically shifts to the connection rate if it is set to &B0.

DESCRIPTION

The retrain sequence occurs at 2400 and 9600 bps. It is a resynchronization sequence performed when one of the connected modems senses that problems on the line may affect data reliability. The procedure is essentially transparent to users.

The following is an example of retrain events:

1. The Courier HST's receiver, sensing a need to retrain, clamps RX to MARKs.
2. The remote modem, after receiving about 100 ms of analog signals (a pattern of  $\overline{?} \overline{?}$  is usually output), clamps RX data to MARKs.
3. After the training sequence, approximately one second, the Courier unclamps RX data and turns HS ON.
4. The remote modem reenters Data Mode.

---

**APPENDIX E-4  
PBX, DEDICATED LINE, AND LEASED LINE OPERATIONS**

The following operations apply in installations where the modem is not directly connected to the public-access switched telephone network.

**Key System  
PBX Installations  
(RJ12/RJ13 Jacks)**

RJ12 and RJ13 phone jacks have two leads (A and A1) in addition to those on the common RJ11 jack. When the connected phone or modem goes off hook, the A/A1 leads are shorted, causing the PBX off-hook indicator for that extension to light, indicating that the line is busy. If you're using either an RJ12 or RJ13 jack, set DIP switch 7 **DOWN** so that the off-hook indicator lights when the modem goes off hook.

*Calling an  
Outside Party*

To have the modem make an outside call, follow the auto-dial instructions in Chapter 6, but insert the sequence used to obtain an outside line, followed by a comma, before the phone number in the Dial command.

The off-hook indicator on the PBX should show the extension as busy if DIP switch 7 is **DOWN**.

*Internal Calling*

To call another modem on the system, use the Dial command described in Chapter 6 with the number of the extension you wish to call. If set to Auto Answer, the called modem automatically answers on the incoming ring. The off-hook indicators on the PBX should show both extensions as busy if DIP switch 7 is **DOWN** on both modems.

**User-Installed  
or Leased  
Telephone Line**

These lines are often referred to as dedicated or private lines. User-installed lines are most commonly 2-wire lines, similar to the 2-wire lines that connect residential phones to the public switched network. Lines leased from the telephone company are 4-wire lines, often designated as 3002 Analog Circuits. In some installations the telephone company also installs 4-wire to 2-wire converters at each end of the connection. For optimal operations, we recommend that the physical length of these lines not exceed 5 miles.

In both types of installation there is a continuous point-to-point connection between two modems. No dialing of phone numbers is required. To establish the connection, follow these steps:

1. Decide which modem is to be the Originate modem and which the Answer modem. The originate and answer frequencies must be defined for the modems to communicate.
2. First put the calling modem in Originate Mode with the manual Dial command:

**ATD <cr>**

**NOTE:** Be sure the modem is not set to X2, X4, X6, or X7, or it will return the NO DIAL TONE result code and hang up.

3. Then put the answering modem in Answer Mode with the manual Answer command:

**ATA <cr>**

**NOTE:** If there is an interruption in the communications link (a strike to the line due to weather or some other problem), repeat steps 2 and 3 to reestablish the link.

The Courier HST recognizes the ASCII ENQ/ACK characters exchanged between the Hewlett Packard host computer and its terminals. The HP host sends the terminal an ENQ character at predefined intervals, and sends no more data until the terminal responds with an ACK character.

Courier HST modems manage this ENQ/ACK protocol so that communication is speeded up, thereby enabling HP terminals to achieve high speeds on dial-up lines. Special Received Data flow control settings (the &I command) *are required for HP users.*

Follow these guidelines:

1. Use one of the &I settings given here for both Normal and error control (ARQ) sessions, i.e., for all &M settings.
2. Do not use a software setting for Transmit Data flow control. Set the modem only to &H0 or &H1, according to the guidelines in Chapter 4.
3. Set the Courier HST to Host Mode if it is attached to the host computer, or to Terminal Mode if it is attached to a terminal:

Host Mode            **AT&l3 <cr>**

Terminal Mode      **AT&l4 <cr>**



**APPENDIX F  
TECHNICAL SPECIFICATIONS**

<b>Compatibility</b>	<p>USR-HST, 9600 bps, asynchronous, asymmetric (9600/300 bps), trellis-coded modulation, Quadrature Amplitude Modulation (QAM)</p> <p>CCITT recommendation V.22bis, 2400/1200 bps, asynchronous, Quadrature Amplitude Modulation (QAM)</p> <p>Bell 212A, 1200 bps, asynchronous, Differential Phase Shift Keying (DPSK)</p> <p>Bell 103, 300 bps, asynchronous, Frequency Shift Keying (FSK)</p> <p>USRobotics HST error control at 9600 bps</p> <p>Microcom Networking Protocol (MNP), Service Classes 1, 2, 3 at 2400/1200 bps</p> <p>RS-232C terminal/modem interface</p> <p>Superset of industry standard AT command set and DIP switches</p>
<b>Phone Line Interface</b>	RJ11, RJ12, RJ13, RJ41, RJ45 phone jacks
<b>Communications Channel</b>	Full/half duplex on 2-wire dial-up, dedicated, or leased phone lines, demand-driven high speed channel turnaround
<b>Data Rates</b>	300, 1200, 2400, 9600 bits per second
<b>Operational Modes</b>	Auto Dial/Answer, Manual Originate/Answer
<b>Dialing</b>	Rotary (pulse 0–9), Touch-Tone (DTMF 0–9, #, *), a-z when in Quote (") Mode
<b>Data Format</b>	Binary, serial, asynchronous; defaults to 7-bit word length, even parity

Start Bits	Data Bits	Parity	Stop Bits
1	7	Even, Odd, Mark, Space	1
1	7	None, Even, Odd, Mark, Space	2
1	8	None	1,2

<b>Front Panel Indicators</b>	HS	High Speed (9600 bps)
	AA	Auto Answer/Answer
	CD	Carrier Detect
	OH	Off Hook
	RD	Receive Data
	SD	Send Data
	TR	Terminal Ready (DTR)
	MR	Modem Ready/Power
	RS	Request to Send
	CS	Clear to Send
	ARQ	HST/MNP connection established
	AL	Analog Loopback Self-Test

**Programmable S-Registers**

Values in parentheses are defaults:

- Number of rings on which to answer (1)
- ASCII character definitions, decimal: escape code (43), Carriage Return (13), Line Feed (10), Backspace (8)
- Timing: Wait before dialing (2 sec)
  - Carrier Detect wait (30 sec)
  - Pause in Dial, Repeat commands (2 sec)
  - Remote Carrier Detect before local recognition (0.6 sec)
  - Disconnect at loss of carrier (0.7 sec)
  - Escape code guard time (1 sec)
  - Touch-Tone duration, spacing (70 Ms)
  - Break length, to DTE (100 Ms)
  - Modem self-testing (0, Data Mode)
  - Inactivity Timer (0, disabled)

**Switch Functions**

Externally accessible. Values in parentheses are factory settings: UP = OFF (open), DOWN = ON (closed).

- Volume control
- DTR override (DOWN)
- Result code mode (UP, verbal)
- Result code display (DOWN, displayed)
- Command Mode echo (UP, echo ON)
- Auto Answer (DOWN, AA suppressed)
- CD override (DOWN)
- RJ11/RJ13 jack (UP, RJ11)
- Smart/Dumb mode (DOWN, Smart)
- Online Escape code with/without disconnect (DOWN, no disconnect)
- Load NRAM defaults/ROM factory settings (UP, NRAM)
- RS-232C Modem/Terminal data interface (UP, normal assignments of Pins 2 and 3)

Flow Control Buffer	4 kbytes
Command Buffer	40 characters, exclusive of AT prefix, Carriage Return and spaces
Control Commands	<p>User-programmable nonvolatile memory (NRAM)</p> <p>Fixed/variable DTE and link rates</p> <p>Error control or error control/normal modes</p> <p>Error control result codes enabled/disabled</p> <p>Transmit data flow control (hardware, software)</p> <p>Received data flow control (hardware, software)</p> <p>Command mode, online echoing</p> <p>Verbal/numeric result codes</p> <p>Standard, Extended, Advanced result code sets</p> <p>Result code display ON/OFF</p> <p>Speaker OFF, ON until CD, ON through CD and data transmission, ON after last digit dialed until CD</p> <p>Command Mode/online toggle</p> <p>Voice/data communications</p> <p>Adaptive dialing</p> <p>Fast dialing, search for dial tone</p> <p>Wait for second dial tone, then continue</p> <p>Wait for answer, then continue</p> <p>Dial alphabetic string</p> <p>Dial one of four phone numbers stored in NRAM</p> <p>Flash switch-hook to transfer call</p> <p>Reset to NRAM defaults</p> <p>Load ROM factory settings</p> <p>Request to Send (RTS) override</p> <p>Data Set Ready (DSR) override</p> <p>Break handling</p>
Test Options	<p>Analog loopback (2400/1200/300 bps)</p> <p>Dial test</p> <p>Test pattern (2400/1200/300 bps)</p> <p>Analog loopback with test pattern (2400/1200/300 bps)</p>
Call Progress Codes	<p><b>NO DIAL TONE</b></p> <p><b>BUSY</b></p> <p><b>NO ANSWER</b></p> <p><b>RINGING</b></p> <p><b>VOICE</b></p>

## COURIER HST

---

Equalization	Adaptive
Transmitter	USR-HST
Carrier	Originate Mode: 350 Hz
Frequencies	Answer Mode: 1800 Hz
	V.22bis, Bell 212A
	Originate Mode: 1200 Hz
	Answer Mode: 2400 Hz
	Bell 103
	Originate Mode:
	Mark: 1270 Hz
	Space: 1070 Hz
	Answer Mode:
	Mark: 2225 Hz
	Space: 2025 Hz
Receiver	USR-HST
Carrier	Originate Mode: 1800 Hz
Frequencies:	Answer Mode: 350 Hz
	V.22bis, Bell 212A
	Originate Mode: 2400 Hz
	Answer Mode: 1200 Hz
	Bell 103
	Originate Mode:
	Mark: 2225 Hz
	Space: 2025 Hz
	Answer Mode:
	Mark: 1270 Hz
	Space: 1070 Hz
Certification	FCC Part 68 & Part 15, Subpart J, Class B Domestic; DOC (Canada)
Power Adapter	UL listed, CSA approved, Supply voltage: 115 VAC, 60 Hz, 16 VAC Output
Power Consumption	10 watts
Failed Call Timeout	30-sec. default, programmable 2–255 sec.
Answer Tone Timeout	30 sec.
Answer Tone Detector	2150–2300 Hz

Loss of Carrier Timeout	(Disconnect Timer) 0.7-sec. default, programmable 0.2–25.5 sec.
Receive Sensitivity	-43 dBm
Transmit Level	- 9 dBm
Transmitter Frequency Tolerance	.01 %
Size	8.30 x 12.65 x 1.57 inches



*Cross-references in the following definitions are printed in boldface.*

Analog Loopback	A modem self-test in which data from the keyboard is sent to the modem's transmitter, modulated into <b>analog</b> form, looped back to the receiver, demodulated into <b>digital</b> form, and returned to the screen for verification. Tests either the modem's originate or answer frequency.
Analog Signals	Continuous, varying waveforms such as the voice tones carried over phone lines. Contrast with <b>digital signals</b> .
Answer Mode	A state in which the modem transmits at the predefined high frequency of the communications channel and receives at the low frequency. The transmit/receive frequencies are the reverse of the calling modem which is in <b>Originate Mode</b> .
ARQ	Automatic Repeat Request. A general term for error control protocols which feature error-detection and automatic retransmission of defective blocks of data. ► See <b>HST</b> and <b>MNP</b> .
ASCII	American Standard Code for Information Interchange. A 7-bit binary code (0s, 1s) used to represent letters, numbers, and special characters such as \$, !, and /. Supported by almost every computer and terminal manufacturer. ► See Appendix B-6 for decimal and hexadecimal code equivalents.
Asynchronous Transmission	Data transmission in which the length of time between transmitted characters may vary. Because the time lapses between transmitted characters are not uniform, the receiving modem must be signaled as to when the data bits of a character begin and when they end. The addition of Start and Stop bits to each character serves this purpose. Compare <b>Synchronous Transmission</b> .
Auto Answer	A feature in modems enabling them to answer incoming calls over the phone lines without the use of a telephone receiver.
Auto Dial	A feature in modems enabling them to dial phone numbers over the phone system without the use of a telephone transmitter.
Baud Rate	The number of discrete signal events per second occurring on a communications channel. Although not technically accurate, baud rate is commonly used to mean <b>bit rate</b> .

Binary Digit	A 0 or 1, reflecting the use of a binary numbering system (only two digits). Used because the computer recognizes either of two states, OFF or ON. Shortened form of binary digit is "bit."
Bit Rate	The number of <b>binary digits</b> or bits transmitted per second ( <b>bps</b> ). Communications channels using telephone channel modems are established at set bit rates, commonly 110, 300, 1200, 2400, 4800, 9600, and 144000.
BPS	The bits ( <b>binary digits</b> ) per second rate.
Buffer	A memory area used as temporary storage during input/output operations. Two examples in the Courier HST are the command buffer (last issued command) and the flow control buffer (for data flow control and storing copies of transmitted <b>frames</b> until they are positively acknowledged by the receiving modem).
Byte	A group of <b>binary digits</b> stored and operated upon as a unit. A byte may have a coded value equal to a character in the ASCII code (letters, numbers), for example, or have some other value meaningful to the computer. In user documentation, the term usually refers to 8-bit units or characters. 1 kilobyte = 1,024 bytes or characters; 64k = 65,536 bytes or characters.
Carrier	A continuous frequency capable of being either modulated or impressed with another information-carrying signal. Carriers are generated and maintained by modems via the transmission lines of the telephone companies.
CCITT	An international organization that defines standards for telegraphic and telephone equipment. For example, the Bell 212A standard for 1200 bps communication in North America is observed internationally as CCITT V.22. For 2400 bps communication, most U.S. manufacturers observe V.22 <i>bis</i> . The initials CCITT represent the French name; in English it's known as the International Telegraph and Telephone Consultative Committee.
Character	A representation, coded in <b>binary digits</b> , of a letter, number, or other symbol.
Characters Per Second	A data transfer rate generally estimated from the bit rate and the character length. For example, at 2400 bps, 8-bit characters with Start and Stop bits (for a total of ten bits per character) will be transmitted at a rate of approximately 240

	characters per second (cps). Some protocols, such as USR-HST and MNP-Service Class 3, employ advanced techniques to increase cps. When the Courier HST is set for maximum throughput, as described in Chapter 3, 140 characters in addition to the standard 960 can be transmitted for a total of 1100 cps.
Cyclic Redundancy Checking (CRC)	An error-detection technique consisting of a cyclic algorithm performed on each block or <b>frame</b> of data by both sending and receiving modems. The sending modem inserts the results of its computation in each data block in the form of a CRC code. The receiving modem compares its results with the received CRC code and responds with either a positive or negative acknowledgment. In the ARQ protocol implemented in the Courier HST, the receiving modem accepts no more data until a defective block is received correctly.
Data Communications	A type of communications in which computers and terminals are able to exchange data over an electronic medium.
DCE	Data Communication (or Circuit-Terminating) Equipment. In this manual, the dial-up modems that establish and control the data link via the telephone network.
DTE	Data Terminal (or Terminating) Equipment. The device, such as a personal computer, terminal, or mainframe, that generates or is the final destination of data.
Dedicated Line	Often used to describe a user-installed phone line, or one leased from the telephone company, that provides a continuous point-to-point connection between two modems, hence “dedicated” to those two devices. The line is “non-switched”: the connection does not require dialing into the phone company’s central switching equipment.
Default	Any setting assumed, at startup or reset, by the computer’s software and attached devices, and operational until changed by the user.
Digital Signals	Discrete, uniform signals. In this manual, the term refers to the <b>binary digits 0 and 1</b> .
Duplex	Indicates a communications channel capable of carrying signals in both directions. ➤ See <b>Half Duplex, Full Duplex</b> .
Equalization	A compensation circuit designed into modems to counteract certain distortions introduced by the telephone channel. Two types are used: fixed (compromise) equalizers and those that adapt to channel conditions.

Error Control	Various techniques which check the reliability of characters ( <b>Parity</b> ) or blocks of data. The Courier's error control protocol provides error control through error detection ( <b>CRC</b> ) and retransmission of errored frames ( <b>ARQ</b> ).
Flow Control	A mechanism that compensates for differences in the flow of data input to and output from a modem or other device.
Frame	A data communications term for a block of data with header and trailer information attached. The added information usually includes a frame number, block size data, error-check codes, and Start/End data.
Full Duplex	Signal flow in both directions at the same time. In microcomputer communications, may refer to the suppression of the online <b>Local Echo</b> . The receiving computer may provide a <b>Remote Echo</b> .
Half Duplex	Signal flow in both directions, but only one way at a time. In microcomputer communications, may refer to activation of the online <b>Local Echo</b> , which causes the modem to send a copy of the transmitted data to the screen of the sending computer.
HST	High Speed Technology, part of the trademark for USRobotics' USR-HST, a proprietary signaling scheme, design and protocol for 9600 bps modems. USR-HST incorporates trellis-coded modulation, for greater immunity from variable phone line conditions, and asymmetric modulation for more efficient use of the phone channel. HST also represents the enhanced error control protocol at 9600 bps that is similar to and compatible with <b>MNP</b> error control at 2400/1200 bps.
Local Echo	A modem feature that enables the modem to send copies of keyboard commands and transmitted data to the screen. When the modem is in Command Mode (not online to another system) the local echo is invoked through the ATE1 command. The command causes the modem to display your typed commands. When the modem is online to another system, the local echo is invoked through the ATF0 command. This command causes the modem to display the data it transmits to the remote system.
MNP	Microcom Networking Protocol. An <b>error control</b> protocol developed by Microcom, Inc. and now in the public domain. The protocol ensures error-free transmission up to

---

	2400 bps through error detection ( <b>CRC</b> ) and retransmission of errored <b>frames</b> .
Modem	<p>A device that transmits/receives computer data through a communications channel such as radio or telephone lines. The Courier is a telephone channel modem that modulates, or transforms, <b>digital signals</b> from a computer into a form that can be carried successfully on a phone line. It also demodulates signals received from the phone line back to digital signals before passing them to the receiving computer.</p> <p>Intelligent modems with built-in software, such as the USRobotics modem described in this manual, simplify using phone networks for data communications.</p>
Nonvolatile Memory (NVRAM)	User-programmable random access memory whose data is retained when modem power is turned off. Used in the Courier HST to store a user-defined default configuration loaded into random access memory ( <b>RAM</b> ) at power on.
OFF/ON Hook	Modem operations which are the equivalent of manually lifting a phone receiver (taking it off hook) and replacing it (going on hook).
Originate Mode	A state in which the modem transmits at the predefined low frequency of the communications channel and receives at the high frequency. The transmit/receive frequencies are the reverse of the called modem which is in <b>Answer Mode</b> .
Parallel Transmission	<p>The transfer of data characters using parallel electrical paths for each bit of the character, for example, 8 paths for 8-bit characters. Data is stored in computers in parallel form, but may be converted to serial form for certain operations.</p> <p>► See <b>Serial Transmission</b>.</p>
Parity	<p>An error-detection method that checks the validity of a transmitted character. Character checking has been surpassed by more reliable and efficient forms of block-checking, including XMODEM, a public domain protocol used in some telecommunications software, and the enhanced <b>ARQ</b> protocols implemented in the Courier HST.</p> <p>The same type of parity must be used by two communicating computers, or both may omit parity. When parity is used, a parity bit is added to each transmitted character. The bit's value is 0 or 1, to make the total number of 1s in the</p>

	character even or odd, depending on which type of parity is used.
Protocol	A system of rules and procedures governing communications between two or more devices. Protocols vary, but communicating devices must follow the same protocol in order to exchange data. The format of the data, readiness to receive or send, error detection, and error handling are only a few of the operations defined in a protocol.
RAM	Random Access Memory. Memory that is available for use when the modem is turned on and clears of all information when the power is turned off. The Courier HST's RAM holds the current operational settings, a flow control <b>buffer</b> , and a command buffer.
Remote Echo	A copy of the data received by the remote system, returned to the sending system and displayed on the screen. Remote echoing is a function of the remote system.
ROM	Read Only Memory. Permanent memory, not user-programmable. The Courier HST's factory settings are stored in ROM and can be read (loaded) into RAM as an operational configuration.
Serial Transmission	The transfer of data characters one bit at a time, sequentially, using a single electrical path. ➤ See <b>Parallel Transmission</b> .
Start/Stop Bits	The signaling bits attached to a character before the character is transmitted during <b>Asynchronous Transmission</b> .
Synchronous Transmission	A form of transmission in which groups of data bits are sent at regular intervals. Because the timing is uniform, no <b>Start</b> or <b>Stop bits</b> are required. ➤ See <b>Asynchronous Transmission</b> .
Terminal	A device whose keyboard and display are used for sending and receiving data over a communications link. Differs from a microcomputer in that it has no internal processing capabilities. Used to enter data into or retrieve processed data from a system or network.
Terminal Mode	An operational mode required for microcomputers to transmit data. In <b>Terminal Mode</b> the computer acts as if it were a standard terminal such as a teletypewriter, rather than a data processor. Keyboard entries go directly to the modem, whether the entry is a modem command or data to be

	transmitted over the phone lines. Received data is output directly to the screen. The more popular communications software products control Terminal Mode as well as enable more complex operations, including file transmission and saving received files.
Throughput	The amount of actual user data transmitted per second without the overhead of protocol information such as Start and Stop bits or <b>frame</b> headers and trailers. Compare <b>characters per second</b> .
Transmission Rate	Same as <b>Bit Rate</b> .
V.22bis	The international <b>CCITT</b> standard for modem communications at 2400 bps. The standard includes an automatic data rate fallback to 1200 bps and compatibility with Bell 212A/V.22 modems.
Word Length	The number of bits in a character without parity, start or stop bits.
XON/XOFF	Standard <b>ASCII</b> control characters used to tell an intelligent device to stop/resume transmitting data. In most systems typing <Ctrl>-S sends the XOFF character. Some devices, including the Courier, understand <Ctrl>-Q as XON; others interpret the pressing of any key after <Ctrl>-S as XON.



**A**

- A:A1 shorting, DIP switch 7, B-3.2, E-4.1
- ACK character, App. E-5
- Adaptive dialing, 1-2, 5-4, 6-3
- Advanced result code set, 5-3-5-4
- Analog loopback self-test, 2-5-2-8
- Answer mode
  - auto answer, 6-10
  - DIP switch 5, B-3.1
  - rate recognition, 4-5, App. E-2
  - manual answer, E-1.1, E-4.1
- ARQ (Automatic Repeat Request)
  - CONNECT result codes (&A), 5-5
  - definition, 4-1, A-3
  - escape code during, 6-9
  - flow control requirement, 3-2, 4-2
  - mode select (&M), 4-2
  - operations, A-2-A-3
  - timeout, retransmit maximum, 4-1
  - with Auto Answer, 4-2
- Assembly, modem, 2-2-2-4
  - RS-232C cable requirements, 2-2
- Asymmetric modulation, 1-1, 3-2
- Asterisk (\*), 6-2
- Asynchronous transmission, F-1, Glossary
- ASCII Chart, App. B-6
  - character definitions, 5-8, B-5.1
- Audio monitor (speaker), 5-6-5-7
- Auto dialing, 6-1-6-8
  - Help screen (DS), 7-6
  - quick reference, 3-1
  - stored phone numbers, 3-3, 6-8
- Auto answering, 6-10
  - disabling, 6-10
  - number of rings on which to answer (S0), 7-3, B-5.1
  - with Dip switch 5, 6-10, B-3.2
- Automatic Repeat Request, see ARQ

**B**

- Backspace key, ASCII definition (S5), B-5.1
- Baud rate, see Glossary
- Bits per second (bps)
  - defined, see Glossary
  - rate recognition, 4-5, 6-1, App. E-2
  - setting the, 3-1, 3-2, 4-5-4-6, 6-1
- Break handling (&Y), 5-8
- Break length, modem to terminal (S21), B-5.3

**Buffer**

- command, 6-7
  - flow control, 3-2, 4-3, A-3
- Busy answer, 3-4, 5-4, 6-6

**C**

- Calling another modem, 3-1, 6-1-6-8
  - at another extension, E-4.1
- Call duration reporting (K), 5-7
- Call progress messages, 5-3, 5-4
- Canadian certification (DOC), x, 6-7
- Carrier, defined, 5-6
- Carrier Detect (CD) override (DIP switch 6), 2-5, B-3.2, D-1
- Channel, turnaround, 1-1, 3-2
- CCITT
  - answer tone (B), 6-11
  - defined, Glossary
- Characters per second (cps), 1-1, A-1
  - maximum throughput, 3-2, 4-6
- Clock, Courier (K), 5-7
- Command length, C-1
- Command mode local echo (E), 2-6, 5-5
- Command summary, App. C
- Commands
  - Adaptive dialing (X2-X6), 5-4, 6-3
  - Alphabetical listing, App. C
  - Answer mode, manual (A)
    - analog loopback self-test, 2-7
    - on dedicated or leased lines, E-4.1
    - with voice/data operations, E-1.1
  - ARQ mode select (&M), 3-1, 4-2, 6-9
  - ARQ result codes (&A), 5-5
  - AT (attention), 2-5, C-1
  - Break handling (&Y), 5-8
  - Cancel dialing (any key), 6-6
  - Carriage return (<cr>), 2-5, C-1
    - ASCII definition (S3), B-5.1
    - to enter commands, 2-5
  - Comma (pause), 6-3
  - Command mode local echo (E), 2-6, 5-5
  - Data rate select, 3-1, 3-2, 4-5, 6-1
    - DTE rate (&B), 4-6
    - Link rate (&N), 4-6
  - Data set ready, DSR (&S), 4-7

- Dial (D), 6-2–6-8
  - and return to command state (:), 6-4
  - letter strings (\*), 6-5
  - Help screen (D\$), 7-6
  - stored phone number (DS), 3-3, 6-8
- Disconnect (H, + + +), 6-8, 6-9, 6-10
  - ARQ mode (+ + +), 6-9
  - with analog loopback, 2-8
- Disable transmitter (C), 5-7
- Duplex, 5-6
- Echo, local (E, F), 2-5, 5-6
- Escape code (+ + +), 2-8, 6-8, 6-9
- Factory settings, loading (&F), 5-2
- Flow control, 3-2, 4-2–4-5
  - received data (&I, &R), 4-4, 4-5
  - transmit data (&H), 3-1, 4-3
- Hang up (H, + + +), 6-9, 6-10
  - ARQ mode (+ + +), 6-9
  - with analog loopback, 2-8
- Help screens
  - ampersand commands (&S), 7-5
  - basic commands (S), 7-4
  - dialing (D\$), 7-6
  - S-register functions (SS), 7-5
- HST mode select (&M), 3-1, 4-2
- Inquiry options (I), 7-1
  - call-duration (I3), 5-7, 7-1
  - current settings display (I4), 7-2
  - link diagnostics display (I6), 7-3
  - NRAM settings display (I5), 7-2
- Local echo (E, F), 2-6, 5-5
- MNP mode select (&M), 3-1, 4-2
- Online local echo (F), 5-6
- Pulse dial make/break ratio (&P), 6-8
- Pulse/Touch-Tone dial (P/T), 6-2
- Quiet mode (Q), 5-5
- Receive only, disable transmitter (C), 5-7
- Received data flow control (&I, &R), 4-4, 4-5
- Redial/reexecute previous command
  - one time (A/), 3-4, 6-7
  - continuous, (A>), 3-4, 6-7
- Repeat, continuous (>), 3-4, 6-7
- Reset to NRAM defaults (Z), 5-2
- Response modes (V), 5-3
- Result code sets (X), 5-3–5-4
- Return online after + + + (O), 6-9
- Reverse frequencies (R), 6-6
- Save in NRAM
  - modem settings (&W), 5-1
  - phone numbers (&Zn = s), 5-2
- Settings status display
  - current settings (I4), 7-2
  - NRAM settings (I5), 7-2

- Speaker control (M), 5-6
- S-register settings (Sr = n), B-5.1
  - query specific register (ATSr?), 4-1, 4-3
- Touch-Tone/pulse dial (P/T), 6-2
- Transfer call (!), 6-5
- Transmit data flow control (&H), 3-1, 4-3
- Verbal/numeric response modes (V), 5-3
- Wait for second dial tone (W), 6-5
- Wait for answer (@), 6-6
- Write to NRAM
  - modem settings (&W), 5-1
  - phone numbers (&Zn = s), 5-2
- Compatibility, 1-3, 6-1, F-1
  - error control, 3-1, 4-2
- Computer interface (DTE) speed select (&B), 4-6
- Configuration, general
  - DIP switches, 2-4, App. B-3
  - factory defaults, 5-2, App. B-4
  - interface controls, Ch. 4
  - internal controls, Ch. 5
  - NRAM options, 5-1, App. B-4
  - physical assembly, 2-2–2-4
  - S-registers, App. B-5
- Configuration to call:
  - HST-compatibles, 3-1
  - MNP-compatibles, 3-1
  - non-MNP compatibles, 3-2
- CONNECT messages, 5-3, 5-4, App. E-2
  - ARQ (&A), 5-5
- Connection rate, 3-3, 4-5, E-2.1
  - negotiation, 3-2, 4-5, E-2.1
- Connectors, DTE interface
  - requirements, 2-1–2-2
  - physical assembly, 2-4
  - RS-232C interface definitions, App. B-1
- CRC, cyclic redundancy checking, A-2
- Customer service, USRobotics, vii, D-4

## D

- Data format, 6-1, F-1
- Data rate select, 3-1, 3-2, 4-5–4-6, 6-1
  - DTE rate (&B), 4-6
  - guidelines, 4-6
  - link rate (&N), 4-6
- Data Set Ready (DSR) override (&S), 4-7, B-1.1
- Data Terminal Ready (DTR) override (DIP switch 1), 2-5, B-1.1, B-3.1, D-1
- DCE, defined, 4-1
- Defaults, 5-2, App. B-4, App. C
- Dial, auto
  - at a glance, 3-1–3-2
  - commands, functions, 6-2–6-8
  - stored phone number (DSn), 3-3, 6-8

## Dialing type

- adaptive, 1-2, 5-4, 6-3
- pulse/tone, 6-2

Department of Communications (DOC), x, 6-7

Digital networks, 2-1

Digital signals, see Glossary

DIP switches, 2-4, App. B-3

- auto answer, 6-10
- CD override, D-1
- disconnect/hang up, 6-9, 6-10
- DTR override, D-1
- escape code operations, 6-9
- local echo, 2-6, 5-5
- result code display (quiet mode), 5-5, D-1, D-2
- Result codes verbal/numeric, 5-3, D-1
- RS-232C DTE interface, B-1.1
- Single/multiphone installation, E-4

Disconnecting (H, + + +), 6-8, 6-9, 6-10

- ARQ mode, 6-9
- reasons (S17, S20), 7-3, B-5.3

DOC, x, 6-7

DTE, defined, 4-1

- speed select (&B), 4-6

DSR override (&S), 4-7

DTR, Data Terminal Ready, B-1.1, B-3.1, D-1

- dropping to force disconnect, 6-9

Dumb mode (DIP switch 8), B-3.2

Duplex, Half/Full, 5-6

**E**

Echo, local 2-6, 5-5, 5-6

ENQ character, App. E-5

Error checking, A-2

Error control, using, 3-1, 4-1-4-2

ERROR message, 5-4

Escape code (+ + +), 6-8, 6-9

- changing ASCII definition (S2), 6-9
- to terminate analog loopback test, 2-8
- under error control, 6-9

Extended result code set, 5-3, 5-4, App. E-2

Extensions

- calling another, E-4.1
- transferring calls to (!), 6-5

**F**

Factory settings, 5-2, App. B-4

Fallback, data rate, 1-2, 3-3, 4-5, App. E-2

FCC certification, ix

Fixed variable rates, 3-3, 4-5, 4-6

Flow control, 3-2, 4-2-4-5

Frame transmission, A-2

Full duplex, 5-6

**H**

Half duplex, 5-6

Hanging up (H, + + +), 6-8, 6-9, 6-10

- reasons (S20), 7-3, B-5.3
- under error control, 6-9

Help screens, see list under "Commands"

Hewlett Packard installations, 2-2, 4-4, App. E-5

HST (High Speed Technology)

- features, 1-1
- error control modes, 3-1, 4-2

**I**

Inactivity timeout (S19), 1-2, 3-4, B-5.3

Indicator lights, 2-5, App. B-2

Installation, 2-2-2-4

**L**

Leased line installation, operations, E-4.1

LED indicators, 2-5, App. B-2

Line feed, ASCII definition (S4), B-5.1

Link interface

- disconnect reasons (S17, S20), 7-3, B-5.3
- operations, 3-3, 4-6, App. E-2
- speed select (&N), 4-6

Load number, DOC, x

Local echo, 2-6, 5-5

Loopback, analog, 2-6-2-8

**M**

Manual, how to use, xi

Memory, modem

- nonvolatile random access (NVRAM), 3-3, 5-1-5-2, App. B-4
- random access (RAM), 7-1, see Glossary
- read only (ROM), 5-2, 7-1, see Glossary

MNP, Microcom Networking Protocol, 1-1, 4-1, A-1 (also see ARQ)

- Service class levels, A-1

Modem

- defaults, App. B-4, App. C
- defined, Glossary
- installation, 2-2-2-4
- problems and solutions, App. D
- repair, vii, D-3

Modulation, 1-1, F-1

Multiphone installations (DIP switch 7), B-3.2, E-4.1

**N**

NO ANSWER result, 5-4, 6-6

NO CARRIER result, 5-4, 6-9

- reason (S20), 4-1-4-2, 7-3, B-5.3

NO DIAL TONE result, 5-4, E-1.1, E-4.1

Nonvolatile random access memory (NRAM)  
  configuring, 5-1, App. B-4  
  defined, 5-1  
  options, App. B-4  
  resetting to (Z), 5-2  
  writing to (&W, &Zn = s), 3-3, 5-2

## O

OK message, 2-5, 5-4  
Online local echo, 5-6  
Operations  
  auto answer, 6-10  
  auto dial, 6-2-6-8  
  error control, 3-1, 4-1, 6-1  
  flow control, 3-2, 4-2  
Originate mode, 2-6, 6-2, E-1.1, E-4.1

## P

Parity, 6-1  
  defined, Glossary  
Party lines, viii, 2-1  
Pause during dial (.), 6-3  
Phone company, connecting to, viii  
Phone line interface, 2-4, F-1  
  dedicated or short line, E-4.1  
  multiphone (DIP switch 7), B-3.2, E-4.1  
PBX installations  
  DIP switch 7, B-3.2  
  procedures, E-4.1  
Phone jacks  
  on Courier, 2-4  
  RJ11C (single phone), 2-1, B-3.2  
  RJ12, RJ13 (multiphone), B-3.2, E-4.1  
Phone number storage (&Zn = s), 3-3, 5-2  
Placing a call, 3-1, 6-2-6-8  
Pound sign (#), 6-3  
Problems  
  and solutions, App. D  
  ARQ compatibility (S17), 7-3, B-5.3  
  digital networks, 2-1  
  party line, viii, 2-1  
Programming rate switching, App. E-2  
Pulse dialing, 6-2

## Q

Quiet mode, 5-5, D-1, D-2

## R

Radio/television interference, ix  
RAM, random access memory, 7-1, see Glossary  
Rate select commands, 4-5  
  DTE rate (&B), 4-6  
  link rate (&N), 4-6  
  guidelines, 4-6

Rate switching, 1-2, 3-2, 3-3, 4-5, App. E-2  
Received data flow control (&I, &R), 4-5, 4-6  
Redial/reexecute

  continuous (A>), 6-7  
  one time (A/), 6-7

Remote echo, 5-6

Repeat mode commands (>, A>), 6-7

Requirements, operating, 2-1

  9600 bps, 3-1

  MNP, 3-1

  ventilation, 2-4

Reset to NRAM defaults (Z), 5-2

Response time, 1-1

Result code sets, 5-3-5-4

Retrain sequence, 1-2, 6-2, App. E-3

Retransmission, 3-2, 4-2, A-2

  maximum to timeout, 4-1

RING result code, 6-10

RINGING result code, 5-4

RJ11C jack, 2-4, B-3.2

RJ12/RJ13 jack (multiphone line), B-3.2, E-4.1

RMA (Return Materials Authorization) number, vii,  
  D-4

ROM, read only memory, 5-2, 7-1

  defined, Glossary

RS-232C interface, App. B-1

  CD override (Pin 8, DIP switch 6), B-2.1, B-3.2,  
  D-1, D-2

  connectors, 2-2, 2-4

  CTS (Pin 5, &H), 4-3

  DSR override (Pin 4, &S), 4-7

  DTR override (Pin 20), B-2.1, D-1

  RTS (&R), 4-5

## S

Serial transmission, see Glossary

Service classes, MNP, A-1

Settings

  interface, Ch. 4

  internal, Ch. 5

  quick reference, Ch. 3

Shorting A/A1, multiphone lines, B-3.2, E-4.1

Speaker (audio monitor), 5-6

Speed recognition, 4-5, 6-1, App. E-2

Speed select

  DTE rate (&B), 4-6

  link rate (&N), 4-6

S-registers, 5-8, 7-3, App. B-5

Standards

  Courier compatibility with, 1-3, 6-1, F-1

  RS-232C, App. B-1, B-3.2

Start/Stop bits, 6-1, F-1

Store phone number (&Zn), 3-3, 5-2

**T**

Technical Specifications, App. F  
Technical Support, USRobotics, vii, D-4  
Telephone company, connecting to, viii  
Television/radio interference, ix  
Terminal (DTE) interface speed select (&B), 4-6  
Terminal Mode, 2-2, 2-5  
Terminology, 4-1, Glossary  
Testing, 2-5  
Throughput, 1-1, 3-2, 4-6, A-1, A-2  
Touch-tones  
    dialing, 6-2  
    timing, spacing (S11), B-5.2  
Transmission rate, 3-1, 4-5, 6-1, App. E-4  
    DTE interface (&B), 3-3, 4-6  
    link interface (&N), 3-3, 4-6  
Transmit data flow control (&H), 3-1, 4-3  
Trellis coded modulation, 1-1  
Turnaround, high speed channel, 1-1, 3-2

**U**

Unattended operation, 6-9, 6-10

**V**

Variable/fixed data rates  
    DTE interface (&B), 3-3, 4-6  
    link interface (&N), 3-3, 4-6  
Ventilation, 2-4  
Voice/data communications  
    configuring for, 2-4  
    using both, App. E-1

**W**

Warranty information, vii  
Word length, 6-1, F-1





**COURIER HST**

**NOTES**

---